

Tone List

A. Piano/E. PIANO

* Pf096–Pf113 are GM/GM2 tones.

No.	Tone Name	Category	MSB	LSB	PC	
1	Pf001	88StageGrand	PNO	087	064	001
2	Pf002	88StgGrand 2	PNO	087	064	002
3	Pf003	88StgGrand 3	PNO	087	064	003
4	Pf004	JUNO Piano 1	PNO	087	064	004
5	Pf005	Rich Grand 1	PNO	087	064	005
6	Pf006	Rich Grand 2	PNO	087	064	006
7	Pf007	Piano+Str 1	PNO	087	064	007
8	Pf008	Fairy Piano	PNO	087	064	008
9	Pf009	Pop Piano 1	PNO	087	064	009
10	Pf010	ConcertGrand	PNO	087	064	010
11	Pf011	Warm Tune	PNO	087	064	011
12	Pf012	Hall Concert	PNO	087	064	012
13	Pf013	Mellow Tune	PNO	087	064	013
14	Pf014	Mono Piano 1	PNO	087	064	014
15	Pf015	Piano+Pad 1	PNO	087	064	015
16	Pf016	Piano+Pad 2	PNO	087	064	016
17	Pf017	Piano+Vox	PNO	087	064	017
18	Pf018	Piano+Str 2	PNO	087	064	018
19	Pf019	Layers	PNO	087	064	019
20	Pf020	Grand Hall	PNO	087	064	020
21	Pf021	Cicada Piano	PNO	087	064	021
22	Pf022	Rhapsody	PNO	087	064	022
23	Pf023	Pop Piano 4	PNO	087	064	023
24	Pf024	Radio Piano	PNO	087	064	024
25	Pf025	Rokkin' pF	PNO	087	064	025
26	Pf026	JD Piano 1	PNO	087	064	026
27	Pf027	JD Piano 2	PNO	087	064	027
28	Pf028	JD Piano&Str	PNO	087	064	028
29	Pf029	SA Dance Pno	PNO	087	064	029
30	Pf030	E-Grand	PNO	087	064	030
31	Pf031	Back E-Grand	PNO	087	064	031
32	Pf032	Dark Grand	PNO	087	064	032
33	Pf033	Grand+FM	PNO	087	064	033
34	Pf034	Blend Piano	PNO	087	064	034
35	Pf035	Piano Oz	PNO	087	064	035
36	Pf036	Meditate Pno	PNO	087	064	036
37	Pf037	FX Piano	PNO	087	064	037
38	Pf038	AmbientPiano	PNO	087	064	038
39	Pf039	Pure EP	EP	087	064	039
40	Pf040	Pure EP Trem	EP	087	064	040
41	Pf041	Stage Phazer	EP	087	064	041
42	Pf042	SA EPiano 1	EP	087	064	042
43	Pf043	FM EP 1	EP	087	064	043
44	Pf044	Pure Wurly 1	EP	087	064	044
45	Pf045	Wurly Trem 1	EP	087	064	045
46	Pf046	VelSpdWurly	EP	087	064	046
47	Pf047	Phase EP 1	EP	087	064	047
48	Pf048	Phase Stg EP	EP	087	064	048
49	Pf049	Flanger EP	EP	087	064	049
50	Pf050	TEL Stage EP	EP	087	064	050
51	Pf051	Vintage EP 1	EP	087	064	051
52	Pf052	Stage EP 1	EP	087	064	052
53	Pf053	StageCabinet	EP	087	064	053
54	Pf054	StageEP Trem	EP	087	064	054
55	Pf055	EP Trem 1	EP	087	064	055
56	Pf056	EP Trem 2	EP	087	064	056
57	Pf057	EP Chorus 1	EP	087	064	057
58	Pf058	EP Chorus 2	EP	087	064	058
59	Pf059	Phase EP 2	EP	087	064	059
60	Pf060	80s EP 1	EP	087	064	060
61	Pf061	Dyno EP	EP	087	064	061
62	Pf062	E.Piano	EP	087	064	062
63	Pf063	Back2the60s	EP	087	064	063
64	Pf064	Tine EP	EP	087	064	064

No.	Tone Name	Category	MSB	LSB	PC	
65	Pf065	LEO EP	EP	087	064	065
66	Pf066	SA EPiano 2	EP	087	064	066
67	Pf067	SA EP Trem	EP	087	064	067
68	Pf068	FM EP mix	EP	087	064	068
69	Pf069	FM-777	EP	087	064	069
70	Pf070	FM EP 2	EP	087	064	070
71	Pf071	FM EP 3	EP	087	064	071
72	Pf072	FM EP 4	EP	087	064	072
73	Pf073	Pure Wurly 3	EP	087	064	073
74	Pf074	EP Layer	EP	087	064	074
75	Pf075	80s EP 2	EP	087	064	075
76	Pf076	Pop EP	EP	087	064	076
77	Pf077	EP Bell 1	EP	087	064	077
78	Pf078	LonesomeRoad	EP	087	064	078
79	Pf079	Age'n'Tines	EP	087	064	079
80	Pf080	Brill TremEP	EP	087	064	080
81	Pf081	Crystal EP	EP	087	064	081
82	Pf082	Vintage Tine	EP	087	064	082
83	Pf083	Mk2 Stg phsr	EP	087	064	083
84	Pf084	Celestial EP	EP	087	064	084
85	Pf085	Psycho EP 1	EP	087	064	085
86	Pf086	TineEP+Pad	EP	087	064	086
87	Pf087	Wurly+Pad	EP	087	064	087
88	Pf088	Dreaming EP	EP	087	064	088
89	Pf089	Balladeer	EP	087	064	089
90	Pf090	Remember	EP	087	064	090
91	Pf091	Vibe EP	EP	087	064	091
92	Pf092	sin(EP)	EP	087	064	092
93	Pf093	Fonky Fonky	EP	087	064	093
94	Pf094	FM EPad	EP	087	064	094
95	Pf095	EP Stack	EP	087	064	095
96	Pf096	Piano 1	PNO	121	0	1
97	Pf097	Piano 1w	PNO	121	1	
98	Pf098	European Pf	PNO	121	2	
99	Pf099	Piano 2	PNO	121	0	2
100	Pf100	Piano 2w	PNO	121	1	
101	Pf101	Piano 3	PNO	121	0	3
102	Pf102	Piano 3w	PNO	121	1	
103	Pf103	Honky-tonk	PNO	121	0	4
104	Pf104	Honky-tonk 2	PNO	121	1	
105	Pf105	E.Piano 1	EP	121	0	5
106	Pf106	St.Soft EP	EP	121	1	
107	Pf107	FM+SA EP	EP	121	2	
108	Pf108	Wurly	EP	121	3	
109	Pf109	E.Piano 2	EP	121	0	6
110	Pf110	Detuned EP 2	EP	121	1	
111	Pf111	St.FM EP	EP	121	2	
112	Pf112	EP Legend	EP	121	3	
113	Pf113	EP Phase	EP	121	4	

ORGAN/KEYBOARD

* Ky106–Ky143 are GM/GM2 tones.

No.	Tone Name	Category	MSB	LSB	PC	
114	Ky001	HardRockORG1	ORG	087	064	096
115	Ky002	HardRockORG2	ORG	087	064	097
116	Ky003	GT Org Stack	ORG	087	064	098
117	Ky004	GT Org Std	ORG	087	064	099
118	Ky005	GT Org Clean	ORG	087	064	100
119	Ky006	Perc Organ 1	ORG	087	064	101
120	Ky007	FullStop Org	ORG	087	064	102
121	Ky008	FullDraw Org	ORG	087	064	103
122	Ky009	StakDraw Org	ORG	087	064	104
123	Ky010	JUNO PercOrg	ORG	087	064	105
124	Ky011	VKHold4Speed	ORG	087	064	106
125	Ky012	Pop Organ 1	ORG	087	064	107

Tone List

No.	Tone Name	Category	MSB	LSB	PC	
126	Ky013	B Org 1	ORG	087	064	108
127	Ky014	D.Bar Org 1	ORG	087	064	109
128	Ky015	D.Bar Org 6	ORG	087	064	110
129	Ky016	D.Bar Org 7	ORG	087	064	111
130	Ky017	D.Bar Org 8	ORG	087	064	112
131	Ky018	Perc Organ 2	ORG	087	064	113
132	Ky019	X Perc Organ	ORG	087	064	114
133	Ky020	Rhythm'n'B	ORG	087	064	115
134	Ky021	Phono Organ	ORG	087	064	116
135	Ky022	Rochno Org	ORG	087	064	117
136	Ky023	R&B Organ 1	ORG	087	064	118
137	Ky024	R&B Organ 2	ORG	087	064	119
138	Ky025	SuperDistOrg	ORG	087	064	120
139	Ky026	SuperDist Ld	ORG	087	064	121
140	Ky027	Dist Bee	ORG	087	064	122
141	Ky028	LoFi PercOrg	ORG	087	064	123
142	Ky029	60's Org 1	ORG	087	064	124
143	Ky030	Smoky Organ	ORG	087	064	125
144	Ky031	Soap Opera	ORG	087	064	126
145	Ky032	Crummy Organ	ORG	087	064	127
146	Ky033	Aqua Org/Pno	ORG	087	064	128
147	Ky034	Positive Org	ORG	087	065	001
148	Ky035	Chapel Organ	ORG	087	065	002
149	Ky036	Cathedral	ORG	087	065	003
150	Ky037	Grand Pipe	ORG	087	065	004
151	Ky038	Pipe Organ 1	ORG	087	065	005
152	Ky039	Masked Opera	ORG	087	065	006
153	Ky040	Clavi 1	KEY	087	065	007
154	Ky041	Phase Clavi1	KEY	087	065	008
155	Ky042	Phase Clavi2	KEY	087	065	009
156	Ky043	AnalogClavi1	KEY	087	065	010
157	Ky044	Pulse Clavi	KEY	087	065	011
158	Ky045	VintageClavi	KEY	087	065	012
159	Ky046	Cutter Clavi	KEY	087	065	013
160	Ky047	Over-D6	KEY	087	065	014
161	Ky048	Cell Clavi	KEY	087	065	015
162	Ky049	Funky D	KEY	087	065	016
163	Ky050	Funky Line	KEY	087	065	017
164	Ky051	PWM Clavi	KEY	087	065	018
165	Ky052	Biting Clavi	KEY	087	065	019
166	Ky053	Reso Clavi	KEY	087	065	020
167	Ky054	BPF Clavi Ph	KEY	087	065	021
168	Ky055	Snappy Clavi	KEY	087	065	022
169	Ky056	Harpsy Clavi	KEY	087	065	023
170	Ky057	JUNO Harpsi	KEY	087	065	024
171	Ky058	Amadeus	KEY	087	065	025
172	Ky059	Music Bells	BEL	087	065	026
173	Ky060	D50Fantasia1	BEL	087	065	027
174	Ky061	Friends Bell	BEL	087	065	028
175	Ky062	FM Syn Bell	BEL	087	065	029
176	Ky063	Dreaming Box	BEL	087	065	030
177	Ky064	Himalaya Ice	BEL	087	065	031
178	Ky065	Wine Glass	BEL	087	065	032
179	Ky066	MuBox Pad	BEL	087	065	033
180	Ky067	Pop Bell	BEL	087	065	034
181	Ky068	Candy Bell	BEL	087	065	035
182	Ky069	FM Heaven	BEL	087	065	036
183	Ky070	JUNO Celesta	BEL	087	065	037
184	Ky071	Celesta Trem	BEL	087	065	038
185	Ky072	Glocken	BEL	087	065	039
186	Ky073	Music Box 1	BEL	087	065	040
187	Ky074	Kalimbells	BEL	087	065	041
188	Ky075	JUNO Bell	BEL	087	065	042
189	Ky076	Grained Bell	BEL	087	065	043
190	Ky077	Chime	BEL	087	065	044
191	Ky078	Bell Ring	BEL	087	065	045
192	Ky079	Tubular Bell	BEL	087	065	046
193	Ky080	5th Key	BEL	087	065	047
194	Ky081	Bell Monitor	BEL	087	065	048

No.	Tone Name	Category	MSB	LSB	PC	
195	Ky082	TubyRuesday	BEL	087	065	049
196	Ky083	Step Ice	BEL	087	065	050
197	Ky084	Vibe Trem 1	MLT	087	065	051
198	Ky085	Pure Vibe	MLT	087	065	052
199	Ky086	Ringy Vibes	MLT	087	065	053
200	Ky087	Airie Vibez	MLT	087	065	054
201	Ky088	JUNO Marimba	MLT	087	065	055
202	Ky089	Soft Marimba	MLT	087	065	056
203	Ky090	FM Wood	MLT	087	065	057
204	Ky091	Xylo	MLT	087	065	058
205	Ky092	Ethno Keys	MLT	087	065	059
206	Ky093	Synergy MLT	MLT	087	065	060
207	Ky094	JUNO SteelDr	MLT	087	065	061
208	Ky095	50' SteelDrms	MLT	087	065	062
209	Ky096	Xylosizer	MLT	087	065	063
210	Ky097	AirPluck	MLT	087	065	064
211	Ky098	Toy Box	MLT	087	065	065
212	Ky099	Icy Keys	MLT	087	065	066
213	Ky100	Squeeze Me!	ACD	087	065	067
214	Ky101	Vodkakordion	ACD	087	065	068
215	Ky102	Guinguette	ACD	087	065	069
216	Ky103	JUNO Harm	HRM	087	065	070
217	Ky104	Blues harp	HRM	087	065	071
218	Ky105	Green Bullet	HRM	087	065	072
219	Ky106	Harpsichord	KEY	121	0	7
220	Ky107	Coupled Hps.	KEY	121	1	
221	Ky108	Harpsi.w	KEY	121	2	
222	Ky109	Harpsi.o	KEY	121	3	
223	Ky110	Clav.	KEY	121	0	8
224	Ky111	Pulse Clav	KEY	121	1	
225	Ky112	Celesta	KEY	121	0	9
226	Ky113	Glockenspiel	BEL	121	0	10
227	Ky114	Music Box	BEL	121	0	11
228	Ky115	Vibraphone	MLT	121	0	12
229	Ky116	Vibraphone w	MLT	121	1	
230	Ky117	Marimba	MLT	121	0	13
231	Ky118	Marimba w	MLT	121	1	
232	Ky119	Xylophone	MLT	121	0	14
233	Ky120	Tubular-bell	BEL	121	0	15
234	Ky121	Church Bell	BEL	121	1	
235	Ky122	Carillon	BEL	121	2	
236	Ky123	Organ 1	ORG	121	0	17
237	Ky124	Trem. Organ	ORG	121	1	
238	Ky125	60's Organ 1	ORG	121	2	
239	Ky126	70's E.Organ	ORG	121	3	
240	Ky127	Organ 2	ORG	121	0	18
241	Ky128	Chorus Or.2	ORG	121	1	
242	Ky129	Perc. Organ	ORG	121	2	
243	Ky130	Organ 3	ORG	121	0	19
244	Ky131	Church Org.1	ORG	121	0	20
245	Ky132	Church Org.2	ORG	121	1	
246	Ky133	Church Org.3	ORG	121	2	
247	Ky134	Reed Organ	ORG	121	0	21
248	Ky135	Puff Organ	ORG	121	1	
249	Ky136	Accordion Fr	ACD	121	0	22
250	Ky137	Accordion It	ACD	121	1	
251	Ky138	Harmonica	HRM	121	0	23
252	Ky139	Bandoneon	ACD	121	0	24
253	Ky140	Crystal	BEL	121	0	99
254	Ky141	Syn Mallet	BEL	121	1	
255	Ky142	Tinkle Bell	BEL	121	0	113
256	Ky143	Steel Drums	MLT	121	0	115

STRINGS/GUITAR

* St109–St154 are GM/GM2 tones.

No.	Tone Name	Category	MSB	LSB	PC	
257	St001	String Ens	STR	087	065	073
258	St002	JUNO Strings	STR	087	065	074
259	St003	Chamber Str1	STR	087	065	075
260	St004	Chamber Str2	STR	087	065	076
261	St005	Staccato	STR	087	065	077
262	St006	Pizzicato	STR	087	065	078
263	St007	Pizz/Stacc	STR	087	065	079
264	St008	Sahara Str	STR	087	065	080
265	St009	Random Mood	STR	087	065	081
266	St010	X Hall Str	STR	087	065	082
267	St011	DelayQuartet	STR	087	065	083
268	St012	Pop Str 1	STR	087	065	084
269	St013	Pop Str 3	STR	087	065	085
270	St014	WhiteStrings	STR	087	065	086
271	St015	JV Strings	STR	087	065	087
272	St016	Marcato	STR	087	065	088
273	St017	Strings 1	STR	087	065	089
274	St018	Strings 2	STR	087	065	090
275	St019	Stringz 101	STR	087	065	091
276	St020	Crossed Bows	STR	087	065	092
277	St021	Small Str	STR	087	065	093
278	St022	Warm Strings	STR	087	065	094
279	St023	DynaStrSect1	STR	087	065	095
280	St024	Full Strings	STR	087	065	096
281	St025	X StrSection	STR	087	065	097
282	St026	Oct Strings	STR	087	065	098
283	St027	Strings 3	STR	087	065	099
284	St028	Monkey Str	STR	087	065	100
285	St029	Hybrid Str 1	STR	087	065	101
286	St030	Biggie Bows	STR	087	065	102
287	St031	Str Stacc mp	STR	087	065	103
288	St032	So Staccato	STR	087	065	104
289	St033	Long/Stacc	STR	087	065	105
290	St034	Pizz/Long	STR	087	065	106
291	St035	Vls PizzHall	STR	087	065	107
292	St036	DelicatePizz	STR	087	065	108
293	St037	Orch Pizz	STR	087	065	109
294	St038	BrightViolin	STR	087	065	110
295	St039	Bright Cello	STR	087	065	111
296	St040	Gang Strangs	STR	087	065	112
297	St041	Clustered!?!	STR	087	065	113
298	St042	Movie Scene	STR	087	065	114
299	St043	Mellow Tron	STR	087	065	115
300	St044	Tronic Str	STR	087	065	116
301	St045	Wind & Str 1	ORC	087	065	117
302	St046	Farewell	ORC	087	065	118
303	St047	Orch & Horns	ORC	087	065	119
304	St048	Soft Orch 1	ORC	087	065	120
305	St049	Henry IX	ORC	087	065	121
306	St050	Ending Scene	ORC	087	065	122
307	St051	Symphonika	ORC	087	065	123
308	St052	Cheezy Movie	HIT	087	065	124
309	St053	Philly Hit	HIT	087	065	125
310	St054	Smear Hit 1	HIT	087	065	126
311	St055	Good Old Hit	HIT	087	065	127
312	St056	Mix Hit 1	HIT	087	065	128
313	St057	Mix Hit 2	HIT	087	066	001
314	St058	Lo-Fi Hit	HIT	087	066	002
315	St059	2ble Action	HIT	087	066	003
316	St060	In da Cave	HIT	087	066	004
317	St061	Housechord	HIT	087	066	005
318	St062	Mod Chord	HIT	087	066	006
319	St063	Dance Steam	HIT	087	066	007
320	St064	JUNO Nylon	AGT	087	066	008
321	St065	Comp Stl Gtr	AGT	087	066	009

No.	Tone Name	Category	MSB	LSB	PC	
322	St066	Pre Mass Hum	AGT	087	066	010
323	St067	Uncle Martin	AGT	087	066	011
324	St068	12str Guitar	AGT	087	066	012
325	St069	Nylon Gtr	AGT	087	066	013
326	St070	SoftNylN Gtr	AGT	087	066	014
327	St071	Wet NylN Gtr	AGT	087	066	015
328	St072	Bright Nylon	AGT	087	066	016
329	St073	Pure Nylon	AGT	087	066	017
330	St074	Nylon Delay	AGT	087	066	018
331	St075	Thick Steel	AGT	087	066	019
332	St076	Wide Ac Gtr	AGT	087	066	020
333	St077	So good !	AGT	087	066	021
334	St078	Jazz Guitar1	EGT	087	066	022
335	St079	Jazz Guitar2	EGT	087	066	023
336	St080	DynoJazz Gtr	EGT	087	066	024
337	St081	Clean Gtr 1	EGT	087	066	025
338	St082	Pick Gtr	EGT	087	066	026
339	St083	Strat Gtr 1	EGT	087	066	027
340	St084	Funk Gtr	EGT	087	066	028
341	St085	StratSeq'nce	EGT	087	066	029
342	St086	Plug n' Gig1	EGT	087	066	030
343	St087	Plug n' Gig2	EGT	087	066	031
344	St088	Kinda Kurt	EGT	087	066	032
345	St089	Nice Oct Gtr	EGT	087	066	033
346	St090	Crimson Gtr	EGT	087	066	034
347	St091	Plugged!!	DGT	087	066	035
348	St092	Punker 1	DGT	087	066	036
349	St093	Rockin' Dly	DGT	087	066	037
350	St094	Loud Gtr	DGT	087	066	038
351	St095	Searing Gtr	DGT	087	066	039
352	St096	Searing COSM	DGT	087	066	040
353	St097	OctSearingGt	DGT	087	066	041
354	St098	Dist.Fingerz	DGT	087	066	042
355	St099	Fuzz Gtr	DGT	087	066	043
356	St100	Crunch Twin	DGT	087	066	044
357	St101	Larsen	DGT	087	066	045
358	St102	Trem-o-Vibe	DGT	087	066	046
359	St103	Touch Drive	DGT	087	066	047
360	St104	Chunk Atk	DGT	087	066	048
361	St105	LP Dist	DGT	087	066	049
362	St106	Hurtling Gtr	DGT	087	066	050
363	St107	Power Chord	DGT	087	066	051
364	St108	Punker 2	DGT	087	066	052
365	St109	Nylon-str.Gt	AGT	121	0	25
366	St110	Ukulele	AGT	121	1	
367	St111	Nylon Gt.o	AGT	121	2	
368	St112	Nylon Gt.2	AGT	121	3	
369	St113	Steel-str.Gt	AGT	121	0	26
370	St114	12-str.Gt	AGT	121	1	
371	St115	Mandolin	AGT	121	2	
372	St116	Steel + Body	AGT	121	3	
373	St117	Jazz Gt.	EGT	121	0	27
374	St118	Pedal Steel	EGT	121	1	
375	St119	Clean Gt.	EGT	121	0	28
376	St120	Chorus Gt.	EGT	121	1	
377	St121	Mid Tone GTR	EGT	121	2	
378	St122	Muted Gt.	EGT	121	0	29
379	St123	Funk Pop	EGT	121	1	
380	St124	Funk Gt.2	EGT	121	2	
381	St125	Jazz Man	EGT	121	3	
382	St126	Overdrive Gt	DGT	121	0	30
383	St127	Guitar Pinch	DGT	121	1	
384	St128	DistortionGt	DGT	121	0	31
385	St129	Feedback Gt.	DGT	121	1	
386	St130	Dist Rtm GTR	DGT	121	2	
387	St131	Gt.Harmonics	EGT	121	0	32
388	St132	Gt.Feedback	EGT	121	1	
389	St133	Violin	STR	121	0	41
390	St134	Slow Violin	STR	121	1	

Tone List

No.		Tone Name	Category	MSB	LSB	PC
391	St135	Viola	STR	121	0	42
392	St136	Cello	STR	121	0	43
393	St137	Contrabass	STR	121	0	44
394	St138	Tremolo Str	STR	121	0	45
395	St139	PizzicatoStr	STR	121	0	46
396	St140	Strings	STR	121	0	49
397	St141	Orchestra	ORC	121	1	
398	St142	60s Strings	STR	121	2	
399	St143	Slow Strings	STR	121	0	50
400	St144	Syn.Strings1	STR	121	0	51
401	St145	Syn.Strings3	STR	121	1	
402	St146	OrchestraHit	HIT	121	0	56
403	St147	Bass Hit	HIT	121	1	
404	St148	6th Hit	HIT	121	2	
405	St149	Euro Hit	HIT	121	3	
406	St150	Atmosphere	AGT	121	0	100
407	St151	Fiddle	STR	121	0	111
408	St152	Gt.FretNoise	AGT	121	0	121
409	St153	Gt.Cut Noise	AGT	121	1	
410	St154	String Slap	AGT	121	2	

BRASS/BASS

* Bs185–Bs234 are GM/GM2 tones.

No.		Tone Name	Category	MSB	LSB	PC
411	Bs001	Bright Brass	BRS	087	066	053
412	Bs002	BreakOut Brs	BRS	087	066	054
413	Bs003	StackTp Sect	BRS	087	066	055
414	Bs004	Tb Section	BRS	087	066	056
415	Bs005	TpTb Sect.	BRS	087	066	057
416	Bs006	Brass Sect 1	BRS	087	066	058
417	Bs007	Brass Sect 2	BRS	087	066	059
418	Bs008	Brass & Sax	BRS	087	066	060
419	Bs009	Simple Tutti	BRS	087	066	061
420	Bs010	Tpts & Tmbs	BRS	087	066	062
421	Bs011	BrassPartOut	BRS	087	066	063
422	Bs012	Full sForza	BRS	087	066	064
423	Bs013	Stereo Brass	BRS	087	066	065
424	Bs014	F.Horns Sect	BRS	087	066	066
425	Bs015	Solo Tp	BRS	087	066	067
426	Bs016	Ambi Tp	BRS	087	066	068
427	Bs017	Horn Chops	BRS	087	066	069
428	Bs018	Mute Tp	BRS	087	066	070
429	Bs019	Harmon Mute	BRS	087	066	071
430	Bs020	Soft Tb	BRS	087	066	072
431	Bs021	Solo Tb	BRS	087	066	073
432	Bs022	Solo Bone	BRS	087	066	074
433	Bs023	Flugel Horn	BRS	087	066	075
434	Bs024	Spit Flugel	BRS	087	066	076
435	Bs025	XP Horn	BRS	087	066	077
436	Bs026	Grande Tuba	BRS	087	066	078
437	Bs027	JUNO Tuba	BRS	087	066	079
438	Bs028	80s Brass 1	SBR	087	066	080
439	Bs029	Wide Syn Brs	SBR	087	066	081
440	Bs030	Poly Brass	SBR	087	066	082
441	Bs031	JP8000 Brass	SBR	087	066	083
442	Bs032	JUNO Brass	SBR	087	066	084
443	Bs033	DetuneSawBrs	SBR	087	066	085
444	Bs034	J-Pop Brass	SBR	087	066	086
445	Bs035	80s Brass 2	SBR	087	066	087
446	Bs036	80s Brass 3	SBR	087	066	088
447	Bs037	80s Brass 4	SBR	087	066	089
448	Bs038	80s Brass 5	SBR	087	066	090
449	Bs039	Ana Brass	SBR	087	066	091
450	Bs040	Soft Brass	SBR	087	066	092
451	Bs041	Ox Brass	SBR	087	066	093
452	Bs042	Syn Brass 1	SBR	087	066	094

No.		Tone Name	Category	MSB	LSB	PC
453	Bs043	Syn Brass 2	SBR	087	066	095
454	Bs044	Xpand Brass1	SBR	087	066	096
455	Bs045	Xpand Brass2	SBR	087	066	097
456	Bs046	Super Saw	SBR	087	066	098
457	Bs047	SoftSynBrass	SBR	087	066	099
458	Bs048	Windy Synth	SBR	087	066	100
459	Bs049	Silky JP	SBR	087	066	101
460	Bs050	Silk Brs Pad	SBR	087	066	102
461	Bs051	X-Saw Brass	SBR	087	066	103
462	Bs052	Cheesy Brass	SBR	087	066	104
463	Bs053	Dual Saw Brs	SBR	087	066	105
464	Bs054	JUNO-106 Brs	SBR	087	066	106
465	Bs055	BreakOut Key	SBR	087	066	107
466	Bs056	Stacked Brs	SBR	087	066	108
467	Bs057	Sax Sect. 1	SAX	087	066	109
468	Bs058	Horny Sax	SAX	087	066	110
469	Bs059	JUNO Sop Sax	SAX	087	066	111
470	Bs060	Solo Sop Sax	SAX	087	066	112
471	Bs061	JUNO AltoSax	SAX	087	066	113
472	Bs062	AltoLead Sax	SAX	087	066	114
473	Bs063	FXM Alto Sax	SAX	087	066	115
474	Bs064	XP TnrBrethy	SAX	087	066	116
475	Bs065	JUNO Tnr Sax	SAX	087	066	117
476	Bs066	Fat TenorSax	SAX	087	066	118
477	Bs067	JUNO BariSax	SAX	087	066	119
478	Bs068	JUNO Flute	FLT	087	066	120
479	Bs069	JUNO Piccolo	FLT	087	066	121
480	Bs070	Clarence.net	WND	087	066	122
481	Bs071	JUNO Oboe	WND	087	066	123
482	Bs072	JUNO E.Horn	WND	087	066	124
483	Bs073	JUNO Bassoon	WND	087	066	125
484	Bs074	Good Old Day	WND	087	066	126
485	Bs075	WindWood	WND	087	066	127
486	Bs076	Ac Bass 1	BS	087	066	128
487	Bs077	Ac Bass 3	BS	087	067	001
488	Bs078	Ulti Ac Bass	BS	087	067	002
489	Bs079	Downright Bs	BS	087	067	003
490	Bs080	Cmp'd Fng Bs	BS	087	067	004
491	Bs081	FingerMaster	BS	087	067	005
492	Bs082	Return2Base!	BS	087	067	006
493	Bs083	Finger Bs 1	BS	087	067	007
494	Bs084	Finger Bs 2	BS	087	067	008
495	Bs085	Finger Bs 3	BS	087	067	009
496	Bs086	Fretless Bs1	BS	087	067	010
497	Bs087	RichFretless	BS	087	067	011
498	Bs088	NewAge Frtls	BS	087	067	012
499	Bs089	P-Bass	BS	087	067	013
500	Bs090	Roomy Bass	BS	087	067	014
501	Bs091	All Round Bs	BS	087	067	015
502	Bs092	Pick Bass 1	BS	087	067	016
503	Bs093	Thumb Up!	BS	087	067	017
504	Bs094	Tubby Mute	BS	087	067	018
505	Bs095	Chicken Bass	BS	087	067	019
506	Bs096	Snug Bass	BS	087	067	020
507	Bs097	Chorus Bass	BS	087	067	021
508	Bs098	A Big Pick	BS	087	067	022
509	Bs099	Slap Bass	BS	087	067	023
510	Bs100	Slap w/Fx	BS	087	067	024
511	Bs101	Basement	BS	087	067	025
512	Bs102	Low Bass	SBS	087	067	026
513	Bs103	Foundation	SBS	087	067	027
514	Bs104	SH Sawtooth	SBS	087	067	028
515	Bs105	Fat RubberBs	SBS	087	067	029
516	Bs106	Garage Bass1	SBS	087	067	030
517	Bs107	Reso SynBs 1	SBS	087	067	031
518	Bs108	TB Dist Bs	SBS	087	067	032
519	Bs109	JUNO Acid Bs	SBS	087	067	033
520	Bs110	Monster Bass	SBS	087	067	034
521	Bs111	Oil Can Bass	SBS	087	067	035

No.	Tone Name	Category	MSB	LSB	PC	
522	Bs112	Pedal Syn Bs	SBS	087	067	036
523	Bs113	Big Mini 1	SBS	087	067	037
524	Bs114	SH-2 Bs	SBS	087	067	038
525	Bs115	SH-101 Bs 1	SBS	087	067	039
526	Bs116	R&B Bass 1	SBS	087	067	040
527	Bs117	Moogy Bass 1	SBS	087	067	041
528	Bs118	JUNO Reso	SBS	087	067	042
529	Bs119	Alpha SynBs1	SBS	087	067	043
530	Bs120	SH Square	SBS	087	067	044
531	Bs121	Pedal Square	SBS	087	067	045
532	Bs122	Doze Bass 1	SBS	087	067	046
533	Bs123	VirtualRnBs1	SBS	087	067	047
534	Bs124	Saw&MG Bass1	SBS	087	067	048
535	Bs125	Square Bass	SBS	087	067	049
536	Bs126	Bs MG	SBS	087	067	050
537	Bs127	Bs Reso	SBS	087	067	051
538	Bs128	Bs SH	SBS	087	067	052
539	Bs129	Bs TB	SBS	087	067	053
540	Bs130	Bs MC	SBS	087	067	054
541	Bs131	Bs Pedal	SBS	087	067	055
542	Bs132	Bs Release	SBS	087	067	056
543	Bs133	Bs Cheeze	SBS	087	067	057
544	Bs134	Mini Like!	SBS	087	067	058
545	Bs135	MC-404 Bass	SBS	087	067	059
546	Bs136	Soft SynBass	SBS	087	067	060
547	Bs137	JUNO-106 Bs	SBS	087	067	061
548	Bs138	Smooth Bass	SBS	087	067	062
549	Bs139	Flat Bass	SBS	087	067	063
550	Bs140	Punch MG 2	SBS	087	067	064
551	Bs141	Electro Rubb	SBS	087	067	065
552	Bs142	Enorjizor	SBS	087	067	066
553	Bs143	LowFat Bass	SBS	087	067	067
554	Bs144	DCO Bass	SBS	087	067	068
555	Bs145	MG+SubOsc Bs	SBS	087	067	069
556	Bs146	Not a Bass	SBS	087	067	070
557	Bs147	SH-1 Bass	SBS	087	067	071
558	Bs148	SH-101 Bs 2	SBS	087	067	072
559	Bs149	Punch MG 1	SBS	087	067	073
560	Bs150	MKS-50 SynBs	SBS	087	067	074
561	Bs151	Gashed Bass	SBS	087	067	075
562	Bs152	Q Bass	SBS	087	067	076
563	Bs153	Super-G DX	SBS	087	067	077
564	Bs154	Kickin' Bass	SBS	087	067	078
565	Bs155	OilDrum Bass	SBS	087	067	079
566	Bs156	Dust Bass	SBS	087	067	080
567	Bs157	Glide-iator	SBS	087	067	081
568	Bs158	Acid Punch	SBS	087	067	082
569	Bs159	Unison Bass	SBS	087	067	083
570	Bs160	Detune Bass	SBS	087	067	084
571	Bs161	Lo Bass	SBS	087	067	085
572	Bs162	Sub Sonic	SBS	087	067	086
573	Bs163	Jungle Bass	SBS	087	067	087
574	Bs164	R&B Bass 7	SBS	087	067	088
575	Bs165	Simply Basic	SBS	087	067	089
576	Bs166	Beepin Bass	SBS	087	067	090
577	Bs167	MC-TB Bass	SBS	087	067	091
578	Bs168	Acdg Bass	SBS	087	067	092
579	Bs169	Loco Voco	SBS	087	067	093
580	Bs170	Unplug it!	SBS	087	067	094
581	Bs171	S&H Bass	SBS	087	067	095
582	Bs172	Destroyed Bs	SBS	087	067	096
583	Bs173	Lo-Fi TB	SBS	087	067	097
584	Bs174	Drop Bass	SBS	087	067	098
585	Bs175	Muffled MG	SBS	087	067	099
586	Bs176	Intrusive Bs	SBS	087	067	100
587	Bs177	TransistorBs	SBS	087	067	101
588	Bs178	JUNO-60 Bass	SBS	087	067	102
589	Bs179	Storm Bass	SBS	087	067	103
590	Bs180	Alpha ResoBs	SBS	087	067	104

No.	Tone Name	Category	MSB	LSB	PC	
591	Bs181	SH-101 Vibe	SBS	087	067	105
592	Bs182	Fazee Bass	SBS	087	067	106
593	Bs183	Hi-Energy Bs	SBS	087	067	107
594	Bs184	Low Nz Bass	SBS	087	067	108
595	Bs185	Acoustic Bs.	BS	121	0	33
596	Bs186	Fingered Bs.	BS	121	0	34
597	Bs187	Finger Slap	BS	121	1	
598	Bs188	Picked Bass	BS	121	0	35
599	Bs189	Fretless Bs.	BS	121	0	36
600	Bs190	Slap Bass 1	BS	121	0	37
601	Bs191	Slap Bass 2	BS	121	0	38
602	Bs192	Synth Bass 1	SBS	121	0	39
603	Bs193	SynthBass101	SBS	121	1	
604	Bs194	Acid Bass	SBS	121	2	
605	Bs195	Clavi Bass	SBS	121	3	
606	Bs196	Hammer	SBS	121	4	
607	Bs197	Synth Bass 2	SBS	121	0	40
608	Bs198	Beef FM Bass	SBS	121	1	
609	Bs199	RubberBass 2	SBS	121	2	
610	Bs200	Attack Pulse	SBS	121	3	
611	Bs201	Trumpet	BRS	121	0	57
612	Bs202	Dark Trumpet	BRS	121	1	
613	Bs203	Trombone	BRS	121	0	58
614	Bs204	Trombone 2	BRS	121	1	
615	Bs205	Bright Tb	BRS	121	2	
616	Bs206	Tuba	BRS	121	0	59
617	Bs207	MutedTrumpet	BRS	121	0	60
618	Bs208	MuteTrumpet2	BRS	121	1	
619	Bs209	French Horns	BRS	121	0	61
620	Bs210	Fr.Horn 2	BRS	121	1	
621	Bs211	Brass 1	BRS	121	0	62
622	Bs212	Brass 2	BRS	121	1	
623	Bs213	Synth Brass1	SBR	121	0	63
624	Bs214	JP Brass	SBR	121	1	
625	Bs215	Oct SynBrass	SBR	121	2	
626	Bs216	Jump Brass	SBR	121	3	
627	Bs217	Synth Brass2	SBR	121	0	64
628	Bs218	SynBrass sfz	SBR	121	1	
629	Bs219	Velo Brass 1	SBR	121	2	
630	Bs220	Soprano Sax	SAX	121	0	65
631	Bs221	Alto Sax	SAX	121	0	66
632	Bs222	Tenor Sax	SAX	121	0	67
633	Bs223	Baritone Sax	SAX	121	0	68
634	Bs224	Oboe	WND	121	0	69
635	Bs225	English Horn	WND	121	0	70
636	Bs226	Bassoon	WND	121	0	71
637	Bs227	Clarinet	WND	121	0	72
638	Bs228	Piccolo	FLT	121	0	73
639	Bs229	Flute	FLT	121	0	74
640	Bs230	Recorder	FLT	121	0	75
641	Bs231	Pan Flute	FLT	121	0	76
642	Bs232	Bottle Blow	FLT	121	0	77
643	Bs233	Whistle	FLT	121	0	79
644	Bs234	Ocarina	FLT	121	0	80

SYNTH/PAD

* Sy450–Sy492 are GM/GM2 tones.

No.	Tone Name	Category	MSB	LSB	PC	
645	Sy001	Porta Lead 1	HLD	087	067	109
646	Sy002	Porta Lead 2	HLD	087	067	110
647	Sy003	Solo Saw Ld	HLD	087	067	111
648	Sy004	Wind Syn Ld	HLD	087	067	112
649	Sy005	GR Lead 1	HLD	087	067	113
650	Sy006	Sync Lead	HLD	087	067	114
651	Sy007	JupiterLead1	HLD	087	067	115
652	Sy008	Alpha Spit 1	HLD	087	067	116

Tone List

No.	Tone Name	Category	MSB	LSB	PC	
653	Sy009	Pro Fat Ld	HLD	087	067	117
654	Sy010	Saw Lead 1	HLD	087	067	118
655	Sy011	Saw Lead 2	HLD	087	067	119
656	Sy012	Saw Lead 3	HLD	087	067	120
657	Sy013	Saw Lead 4	HLD	087	067	121
658	Sy014	Saw Lead 5	HLD	087	067	122
659	Sy015	Saw Lead 6	HLD	087	067	123
660	Sy016	JUNO Lead	HLD	087	067	124
661	Sy017	Jump Poly	HLD	087	067	125
662	Sy018	Octa Juice	HLD	087	067	126
663	Sy019	Octa Saw	HLD	087	067	127
664	Sy020	Octa Sync 1	HLD	087	067	128
665	Sy021	Hot Sync	HLD	087	068	001
666	Sy022	Hot Coffee	HLD	087	068	002
667	Sy023	Phase Lead	HLD	087	068	003
668	Sy024	Waspy Lead 1	HLD	087	068	004
669	Sy025	Follow Me 1	HLD	087	068	005
670	Sy026	Classic Ld 1	HLD	087	068	006
671	Sy027	Digi Lead 1	HLD	087	068	007
672	Sy028	DC Triangle	HLD	087	068	008
673	Sy029	Sqr-Sequence	HLD	087	068	009
674	Sy030	Pure Square	HLD	087	068	010
675	Sy031	Griggley	HLD	087	068	011
676	Sy032	Legato Saw	HLD	087	068	012
677	Sy033	Dual Profs	HLD	087	068	013
678	Sy034	Gwyo Press	HLD	087	068	014
679	Sy035	"Q" DualSaws	HLD	087	068	015
680	Sy036	Mogulator Ld	HLD	087	068	016
681	Sy037	DirtyVoltage	HLD	087	068	017
682	Sy038	Clean?	HLD	087	068	018
683	Sy039	Distortion	HLD	087	068	019
684	Sy040	Syn Lead 1	HLD	087	068	020
685	Sy041	Syn Lead 2	HLD	087	068	021
686	Sy042	X-Sink Delay	HLD	087	068	022
687	Sy043	Destroyed Ld	HLD	087	068	023
688	Sy044	Synchro Lead	HLD	087	068	024
689	Sy045	Sync Tank	HLD	087	068	025
690	Sy046	Sync Ld Mono	HLD	087	068	026
691	Sy047	SyncModulate	HLD	087	068	027
692	Sy048	2krazy Brite	HLD	087	068	028
693	Sy049	Distorted MG	HLD	087	068	029
694	Sy050	Dist Lead	HLD	087	068	030
695	Sy051	Ringmod Lead	HLD	087	068	031
696	Sy052	BodyElectric	HLD	087	068	032
697	Sy053	SonicVampire	HLD	087	068	033
698	Sy054	Stimulation	HLD	087	068	034
699	Sy055	Wire Sync	HLD	087	068	035
700	Sy056	Epic Lead	HLD	087	068	036
701	Sy057	Bag Lead	HLD	087	068	037
702	Sy058	Wezcoast	HLD	087	068	038
703	Sy059	HyperJupiter	HLD	087	068	039
704	Sy060	Vintagolizer	HLD	087	068	040
705	Sy061	C64 Lead	HLD	087	068	041
706	Sy062	303 NRG	HLD	087	068	042
707	Sy063	Feat Lead	HLD	087	068	043
708	Sy064	Cell SquLead	SLD	087	068	044
709	Sy065	Theramax 1	SLD	087	068	045
710	Sy066	Pulse Lead 1	SLD	087	068	046
711	Sy067	Mid Saw Ld	SLD	087	068	047
712	Sy068	On Air	SLD	087	068	048
713	Sy069	Tri Lead 1	SLD	087	068	049
714	Sy070	Sine Lead 1	SLD	087	068	050
715	Sy071	Sqr Lead 1	SLD	087	068	051
716	Sy072	SH Sqr Lead	SLD	087	068	052
717	Sy073	Sineticf	SLD	087	068	053
718	Sy074	JUNO Soft Ld	SLD	087	068	054
719	Sy075	Spooky Lead	SLD	087	068	055
720	Sy076	PeakArpSine	SLD	087	068	056
721	Sy077	Howards Lead	SLD	087	068	057

No.	Tone Name	Category	MSB	LSB	PC	
722	Sy078	SoloNzPeaker	SLD	087	068	058
723	Sy079	R&B Tri Ld 1	SLD	087	068	059
724	Sy080	R&B Tri Ld 2	SLD	087	068	060
725	Sy081	JupiterLead2	SLD	087	068	061
726	Sy082	JupiterLead3	SLD	087	068	062
727	Sy083	Dig-n-Duke	SLD	087	068	063
728	Sy084	Sqr Diamond	SLD	087	068	064
729	Sy085	Soft Lead	SLD	087	068	065
730	Sy086	Soft Saw Ld	SLD	087	068	066
731	Sy087	X-Pulse Lead	SLD	087	068	067
732	Sy088	Mild 2-SawLd	SLD	087	068	068
733	Sy089	Mew Lead	SLD	087	068	069
734	Sy090	Shy Soloist	SLD	087	068	070
735	Sy091	Theramax 2	SLD	087	068	071
736	Sy092	Therasqu	SLD	087	068	072
737	Sy093	GR Lead 2	SLD	087	068	073
738	Sy094	SH-2 Lead	SLD	087	068	074
739	Sy095	Jucy Saw	SLD	087	068	075
740	Sy096	Reso Lead	SLD	087	068	076
741	Sy097	Modulated Ld	SLD	087	068	077
742	Sy098	Synthi Fizz	SLD	087	068	078
743	Sy099	Pulstar Ld	SLD	087	068	079
744	Sy100	Naked Lead	SLD	087	068	080
745	Sy101	JP Saw Lead	SLD	087	068	081
746	Sy102	Violin Lead	SLD	087	068	082
747	Sy103	Mod Lead	SLD	087	068	083
748	Sy104	Tristar	SLD	087	068	084
749	Sy105	Chubby Lead	SLD	087	068	085
750	Sy106	Sneaky Leady	SLD	087	068	086
751	Sy107	Shaku Lead	SLD	087	068	087
752	Sy108	Legato Tkno	SLD	087	068	088
753	Sy109	Reso Saw Ld	SLD	087	068	089
754	Sy110	SliCed Lead	SLD	087	068	090
755	Sy111	Mini Growl	SLD	087	068	091
756	Sy112	Evangelized	SLD	087	068	092
757	Sy113	Air Lead	SLD	087	068	093
758	Sy114	Stacc Heaven	SYN	087	068	094
759	Sy115	Sugar Synth	SYN	087	068	095
760	Sy116	Synth Key	SYN	087	068	096
761	Sy117	Frontier Syn	SYN	087	068	097
762	Sy118	Summer Str	SYN	087	068	098
763	Sy119	JUNO Poly	SYN	087	068	099
764	Sy120	SuperSawSlow	SYN	087	068	100
765	Sy121	Cue Tip	SYN	087	068	101
766	Sy122	Waspy Synth	SYN	087	068	102
767	Sy123	Europe Xpres	SYN	087	068	103
768	Sy124	Squeepy	SYN	087	068	104
769	Sy125	DOC Stack	SYN	087	068	105
770	Sy126	Sweep Lead	SYN	087	068	106
771	Sy127	80s Saws 1	SYN	087	068	107
772	Sy128	Digitaless	SYN	087	068	108
773	Sy129	Flip Pad	SYN	087	068	109
774	Sy130	Short Detune	SYN	087	068	110
775	Sy131	forSequence	SYN	087	068	111
776	Sy132	Memory Pluck	SYN	087	068	112
777	Sy133	Metalic Bass	SYN	087	068	113
778	Sy134	Aqua	SYN	087	068	114
779	Sy135	Round SQR	SYN	087	068	115
780	Sy136	Big Planet	SYN	087	068	116
781	Sy137	Wet Atax	SYN	087	068	117
782	Sy138	Houze Clavi	SYN	087	068	118
783	Sy139	Saw Stack	SYN	087	068	119
784	Sy140	Frgile Saws	SYN	087	068	120
785	Sy141	Steamed Sawz	SYN	087	068	121
786	Sy142	RAVtune	SYN	087	068	122
787	Sy143	Bustranza	SYN	087	068	123
788	Sy144	Digi Saw Syn	SYN	087	068	124
789	Sy145	JP OctAttack	SYN	087	068	125
790	Sy146	Oct Unison	SYN	087	068	126

No.		Tone Name	Category	MSB	LSB	PC
791	Sy147	Xtatic	SYN	087	068	127
792	Sy148	Dirty Combo	SYN	087	068	128
793	Sy149	FM's Attack	SYN	087	069	001
794	Sy150	Digi-vox Syn	SYN	087	069	002
795	Sy151	Fairy Factor	SYN	087	069	003
796	Sy152	Tempest	SYN	087	069	004
797	Sy153	X-Racer	SYN	087	069	005
798	Sy154	TB Booster	SYN	087	069	006
799	Sy155	Syn-Orch/Mod	SYN	087	069	007
800	Sy156	Presssyn	SYN	087	069	008
801	Sy157	High Five	SYN	087	069	009
802	Sy158	Magnetic 5th	SYN	087	069	010
803	Sy159	DigimaX	SYN	087	069	011
804	Sy160	Exhale	SYN	087	069	012
805	Sy161	X-panda	SYN	087	069	013
806	Sy162	Saw Keystep	SYN	087	069	014
807	Sy163	Blue Meanie	SYN	087	069	015
808	Sy164	4mant Cycle	SYN	087	069	016
809	Sy165	Modular	SYN	087	069	017
810	Sy166	Analog Dream	SYN	087	069	018
811	Sy167	DCO Bell Pad	SYN	087	069	019
812	Sy168	Cell Fanta	SYN	087	069	020
813	Sy169	JUNO 5th	SYN	087	069	021
814	Sy170	DoubleBubble	SYN	087	069	022
815	Sy171	JUNO-D Maj7	TEK	087	069	023
816	Sy172	Sweet House	TEK	087	069	024
817	Sy173	Periscope	TEK	087	069	025
818	Sy174	5th Voice	TEK	087	069	026
819	Sy175	HPF Sweep	TEK	087	069	027
820	Sy176	BPF Saw	TEK	087	069	028
821	Sy177	Moon Synth	TEK	087	069	029
822	Sy178	DelyResoSaws	TEK	087	069	030
823	Sy179	JUNO Trance1	TEK	087	069	031
824	Sy180	Trancy Synth	TEK	087	069	032
825	Sy181	Cell Trance	TEK	087	069	033
826	Sy182	Trancy X	TEK	087	069	034
827	Sy183	JUNO Trance2	TEK	087	069	035
828	Sy184	R-Trance	TEK	087	069	036
829	Sy185	Braatz...	TEK	087	069	037
830	Sy186	AllinOneRiff	TEK	087	069	038
831	Sy187	YZ Again	TEK	087	069	039
832	Sy188	Flazzy Lead	TEK	087	069	040
833	Sy189	Coffee Bee	TEK	087	069	041
834	Sy190	TB-Sequence	TEK	087	069	042
835	Sy191	SC-303	TEK	087	069	043
836	Sy192	Dance Saws	TEK	087	069	044
837	Sy193	AluminmWires	TEK	087	069	045
838	Sy194	Fred&Barney	TEK	087	069	046
839	Sy195	Electrostars	TEK	087	069	047
840	Sy196	LoFiSequence	TEK	087	069	048
841	Sy197	MelodicDrums	TEK	087	069	049
842	Sy198	Monkey Arpg	TEK	087	069	050
843	Sy199	TB Wah	TEK	087	069	051
844	Sy200	Waving TB303	TEK	087	069	052
845	Sy201	Digi Seq	TEK	087	069	053
846	Sy202	Seq Saw	TEK	087	069	054
847	Sy203	Reso Seq Saw	TEK	087	069	055
848	Sy204	DetuneSeqSaw	TEK	087	069	056
849	Sy205	Technotribe	TEK	087	069	057
850	Sy206	Teethy Grit	TEK	087	069	058
851	Sy207	Repertition	TEK	087	069	059
852	Sy208	Killerbeez	TEK	087	069	060
853	Sy209	Acid Lead	TEK	087	069	061
854	Sy210	Tranceformer	TEK	087	069	062
855	Sy211	Anadroid	TEK	087	069	063
856	Sy212	Shroomy	TEK	087	069	064
857	Sy213	Noize R us	TEK	087	069	065
858	Sy214	Beep Melodie	TEK	087	069	066
859	Sy215	Morpher	TEK	087	069	067

No.		Tone Name	Category	MSB	LSB	PC
860	Sy216	Power Synth	TEK	087	069	068
861	Sy217	Hoover Again	TEK	087	069	069
862	Sy218	Alpha Said..	TEK	087	069	070
863	Sy219	Ravers Awake	TEK	087	069	071
864	Sy220	Tekno Gargle	TEK	087	069	072
865	Sy221	Tranceiver	TEK	087	069	073
866	Sy222	Techno Dream	TEK	087	069	074
867	Sy223	Techno Pizz	TEK	087	069	075
868	Sy224	VirtualHuman	PLS	087	069	076
869	Sy225	Strobot	PLS	087	069	077
870	Sy226	Strobe	PLS	087	069	078
871	Sy227	Strobe X	PLS	087	069	079
872	Sy228	Mr. Fourier	PLS	087	069	080
873	Sy229	Rhythmic 5th	PLS	087	069	081
874	Sy230	Sorry4theDLY	PLS	087	069	082
875	Sy231	Cell Pad	PLS	087	069	083
876	Sy232	Shape of X	PLS	087	069	084
877	Sy233	ShapeURMusic	PLS	087	069	085
878	Sy234	Synth Force	PLS	087	069	086
879	Sy235	Trance Split	PLS	087	069	087
880	Sy236	Step Trance	PLS	087	069	088
881	Sy237	Chop Synth	PLS	087	069	089
882	Sy238	Euro Teuro	PLS	087	069	090
883	Sy239	Auto Trance1	PLS	087	069	091
884	Sy240	Eureggae	PLS	087	069	092
885	Sy241	Beat Pad	PLS	087	069	093
886	Sy242	TMT Seq Pad	PLS	087	069	094
887	Sy243	ForYourBreak	PLS	087	069	095
888	Sy244	HPF Slicer	PLS	087	069	096
889	Sy245	Sliced Choir	PLS	087	069	097
890	Sy246	Digi-Doo	PLS	087	069	098
891	Sy247	PanningFrmnt	PLS	087	069	099
892	Sy248	Dirty Beat	PLS	087	069	100
893	Sy249	Electrons	PLS	087	069	101
894	Sy250	Protons	PLS	087	069	102
895	Sy251	Brisk Vortex	PLS	087	069	103
896	Sy252	Throbulax	PLS	087	069	104
897	Sy253	Lonizer	PLS	087	069	105
898	Sy254	diGital Pad	PLS	087	069	106
899	Sy255	StepPitShift	PLS	087	069	107
900	Sy256	Pad Pulses	PLS	087	069	108
901	Sy257	Seq-Pad 1	PLS	087	069	109
902	Sy258	DSP Chaos	PLS	087	069	110
903	Sy259	Dance floor	PLS	087	069	111
904	Sy260	Minor Thirds	PLS	087	069	112
905	Sy261	FX World	PLS	087	069	113
906	Sy262	Nu Trance X	PLS	087	069	114
907	Sy263	Auto 5thSaws	PLS	087	069	115
908	Sy264	Cross Talk	PLS	087	069	116
909	Sy265	Reanimation	PLS	087	069	117
910	Sy266	VoX Chopper	PLS	087	069	118
911	Sy267	Trevor's Pad	PLS	087	069	119
912	Sy268	Fantomas Pad	PLS	087	069	120
913	Sy269	Jazzy Arps	PLS	087	069	121
914	Sy270	Keep Running	PLS	087	069	122
915	Sy271	Step In	PLS	087	069	123
916	Sy272	Echo Echo	PLS	087	069	124
917	Sy273	Keep going	PLS	087	069	125
918	Sy274	Arposphere	PLS	087	069	126
919	Sy275	Voco Riff	PLS	087	069	127
920	Sy276	Pulsator	PLS	087	069	128
921	Sy277	Motion Bass	PLS	087	070	001
922	Sy278	Sine Magic	PLS	087	070	002
923	Sy279	JUNO-D Slice	PLS	087	070	003
924	Sy280	Pulsatron	PLS	087	070	004
925	Sy281	Mega Sync	PLS	087	070	005
926	Sy282	Passing by	FX	087	070	006
927	Sy283	Lazer Points	FX	087	070	007
928	Sy284	Retro Sci-Fi	FX	087	070	008

Tone List

No.		Tone Name	Category	MSB	LSB	PC
929	Sy285	Magic Chime	FX	087	070	009
930	Sy286	Try This!	FX	087	070	010
931	Sy287	New Planetz	FX	087	070	011
932	Sy288	Jet Noise	FX	087	070	012
933	Sy289	Chaos 2003	FX	087	070	013
934	Sy290	Control Room	FX	087	070	014
935	Sy291	OutOf sortz	FX	087	070	015
936	Sy292	Scatter	FX	087	070	016
937	Sy293	Low Beat-5	FX	087	070	017
938	Sy294	WaitnOutside	FX	087	070	018
939	Sy295	Breath Echo	FX	087	070	019
940	Sy296	SoundStrange	FX	087	070	020
941	Sy297	Cosmic Pulse	FX	087	070	021
942	Sy298	Faked Piano	FX	087	070	022
943	Sy299	JUNO Crystal	FX	087	070	023
944	Sy300	ResoSweep Dn	FX	087	070	024
945	Sy301	Zap B3 & C4	FX	087	070	025
946	Sy302	PolySweep Nz	FX	087	070	026
947	Sy303	Strange Land	FX	087	070	027
948	Sy304	S&H Voc	FX	087	070	028
949	Sy305	12th Planet	FX	087	070	029
950	Sy306	Scare	FX	087	070	030
951	Sy307	Hillside	FX	087	070	031
952	Sy308	Mod Scanner	FX	087	070	032
953	Sy309	SoundOnSound	FX	087	070	033
954	Sy310	Gasp	FX	087	070	034
955	Sy311	ResoSweep Up	FX	087	070	035
956	Sy312	Magic Wave	FX	087	070	036
957	Sy313	Shangri-La	FX	087	070	037
958	Sy314	CerealKiller	FX	087	070	038
959	Sy315	Cosmic Drops	FX	087	070	039
960	Sy316	Space Echo	FX	087	070	040
961	Sy317	Robot Sci-Fi	FX	087	070	041
962	Sy318	Jazz Scat	VOX	087	070	042
963	Sy319	Jazz Doos	VOX	087	070	043
964	Sy320	Choir Aahs 1	VOX	087	070	044
965	Sy321	Choir Aahs 2	VOX	087	070	045
966	Sy322	Choir Oohs	VOX	087	070	046
967	Sy323	AngelsChoir1	VOX	087	070	047
968	Sy324	AngelsChoir2	VOX	087	070	048
969	Sy325	Syn Opera	VOX	087	070	049
970	Sy326	Angelique	VOX	087	070	050
971	Sy327	Vox Pad 1	VOX	087	070	051
972	Sy328	Vox Pad 2	VOX	087	070	052
973	Sy329	Gospel Oohs	VOX	087	070	053
974	Sy330	Choir&Str	VOX	087	070	054
975	Sy331	SynVox 1	VOX	087	070	055
976	Sy332	SynVox 2	VOX	087	070	056
977	Sy333	Aah Vox	VOX	087	070	057
978	Sy334	Sweet Keys	VOX	087	070	058
979	Sy335	JUNO Synvox	VOX	087	070	059
980	Sy336	Uhhmm	VOX	087	070	060
981	Sy337	Morning Star	VOX	087	070	061
982	Sy338	BeautifulOne	VOX	087	070	062
983	Sy339	Ooze	VOX	087	070	063
984	Sy340	Aerial Choir	VOX	087	070	064
985	Sy341	3D Vox	VOX	087	070	065
986	Sy342	Sample Opera	VOX	087	070	066
987	Sy343	Film Cue	VOX	087	070	067
988	Sy344	Paradise	VOX	087	070	068
989	Sy345	Sad ceremony	VOX	087	070	069
990	Sy346	Lost Voices	VOX	087	070	070
991	Sy347	Beat Vox	VOX	087	070	071
992	Sy348	Talk 2 Me	VOX	087	070	072
993	Sy349	FM Vox	VOX	087	070	073
994	Sy350	Let's Talk!	VOX	087	070	074
995	Sy351	Cosmic Rays	BPD	087	070	075
996	Sy352	Phaser Pad 1	BPD	087	070	076
997	Sy353	PhaseStrings	BPD	087	070	077

No.		Tone Name	Category	MSB	LSB	PC
998	Sy354	Super SynStr	BPD	087	070	078
999	Sy355	80s Str 1	BPD	087	070	079
1000	Sy356	80s Str 2	BPD	087	070	080
1001	Sy357	BreakOut Str	BPD	087	070	081
1002	Sy358	Friends Syn	BPD	087	070	082
1003	Sy359	Comb	BPD	087	070	083
1004	Sy360	Voyager	BPD	087	070	084
1005	Sy361	Stringship	BPD	087	070	085
1006	Sy362	DarknessSide	BPD	087	070	086
1007	Sy363	Fat Stacks	BPD	087	070	087
1008	Sy364	Strings R Us	BPD	087	070	088
1009	Sy365	Electric Pad	BPD	087	070	089
1010	Sy366	Neo RS-202	BPD	087	070	090
1011	Sy367	OB Rezo Pad	BPD	087	070	091
1012	Sy368	Synthi Ens	BPD	087	070	092
1013	Sy369	Giant Sweep	BPD	087	070	093
1014	Sy370	Mod Dare	BPD	087	070	094
1015	Sy371	Cell Space	BPD	087	070	095
1016	Sy372	Digi-Swell	BPD	087	070	096
1017	Sy373	New Year Day	BPD	087	070	097
1018	Sy374	Polar Morn	BPD	087	070	098
1019	Sy375	Distant Sun	BPD	087	070	099
1020	Sy376	PG Chimes	BPD	087	070	100
1021	Sy377	Saturn Rings	BPD	087	070	101
1022	Sy378	Brusky	BPD	087	070	102
1023	Sy379	2.2 Pad 1	BPD	087	070	103
1024	Sy380	SaturnHolida	BPD	087	070	104
1025	Sy381	Neuro-Drone	BPD	087	070	105
1026	Sy382	In The Pass	BPD	087	070	106
1027	Sy383	Polar Night	BPD	087	070	107
1028	Sy384	Cell 5th	BPD	087	070	108
1029	Sy385	MistOver5ths	BPD	087	070	109
1030	Sy386	Gritty Pad	BPD	087	070	110
1031	Sy387	India Garden	BPD	087	070	111
1032	Sy388	BillionStars	BPD	087	070	112
1033	Sy389	Sand Pad	BPD	087	070	113
1034	Sy390	ReverseSweep	BPD	087	070	114
1035	Sy391	HugeSoundMod	BPD	087	070	115
1036	Sy392	Metal Swell	BPD	087	070	116
1037	Sy393	NuSoundtrack	BPD	087	070	117
1038	Sy394	Phat Strings	BPD	087	070	118
1039	Sy395	Hollow	SPD	087	070	119
1040	Sy396	Heaven Pad	SPD	087	070	120
1041	Sy397	Soft OB Pad	SPD	087	070	121
1042	Sy398	Reso Pad	SPD	087	070	122
1043	Sy399	Slow Saw Str	SPD	087	070	123
1044	Sy400	Terra Nostra	SPD	087	070	124
1045	Sy401	Summer Pad	SPD	087	070	125
1046	Sy402	Friends Pad	SPD	087	070	126
1047	Sy403	Pop Pad	SPD	087	070	127
1048	Sy404	Sqr Pad	SPD	087	070	128
1049	Sy405	Silk Pad	SPD	087	071	001
1050	Sy406	WarmReso Pad	SPD	087	071	002
1051	Sy407	Soft Pad	SPD	087	071	003
1052	Sy408	Air Pad	SPD	087	071	004
1053	Sy409	Soft Breeze	SPD	087	071	005
1054	Sy410	JP Strings 1	SPD	087	071	006
1055	Sy411	DelayStrings	SPD	087	071	007
1056	Sy412	NorthStrings	SPD	087	071	008
1057	Sy413	Syn Strings1	SPD	087	071	009
1058	Sy414	OB Strings 1	SPD	087	071	010
1059	Sy415	Strings Pad	SPD	087	071	011
1060	Sy416	R&B SoftPad	SPD	087	071	012
1061	Sy417	Phat Pad	SPD	087	071	013
1062	Sy418	Mystic Str	SPD	087	071	014
1063	Sy419	Glass Organ	SPD	087	071	015
1064	Sy420	Wind Pad	SPD	087	071	016
1065	Sy421	Combination	SPD	087	071	017
1066	Sy422	HumanKindnes	SPD	087	071	018

No.	Tone Name	Category	MSB	LSB	PC	
1067	Sy423	Beauty Pad	SPD	087	071	019
1068	Sy424	Atmospherics	SPD	087	071	020
1069	Sy425	OB Aahs	SPD	087	071	021
1070	Sy426	Vulcano Pad	SPD	087	071	022
1071	Sy427	Cloud #9	SPD	087	071	023
1072	Sy428	Organic Pad	SPD	087	071	024
1073	Sy429	Hum Pad	SPD	087	071	025
1074	Sy430	Vox Pad	SPD	087	071	026
1075	Sy431	Digital Aahs	SPD	087	071	027
1076	Sy432	Tri 5th Pad	SPD	087	071	028
1077	Sy433	Movin Pad	SPD	087	071	029
1078	Sy434	Follow	SPD	087	071	030
1079	Sy435	Consolament	SPD	087	071	031
1080	Sy436	Spacious Pad	SPD	087	071	032
1081	Sy437	JD Pop Pad	SPD	087	071	033
1082	Sy438	JP-8 Phase	SPD	087	071	034
1083	Sy439	Nu Epic Pad	SPD	087	071	035
1084	Sy440	Flange Dream	SPD	087	071	036
1085	Sy441	Evolution X	SPD	087	071	037
1086	Sy442	Angelis Pad	SPD	087	071	038
1087	Sy443	JUNO-106 Str	SPD	087	071	039
1088	Sy444	JupiterMoves	SPD	087	071	040
1089	Sy445	Oceanic Pad	SPD	087	071	041
1090	Sy446	Fairy's Song	SPD	087	071	042
1091	Sy447	Borealis	SPD	087	071	043
1092	Sy448	JX Warm Pad	SPD	087	071	044
1093	Sy449	Analog Bgrnd	SPD	087	071	045
1094	Sy450	Syn.Strings2	SPD	121	0	52
1095	Sy451	Choir Aahs	VOX	121	0	53
1096	Sy452	Chorus Aahs	VOX	121	1	
1097	Sy453	Voice Oohs	VOX	121	0	54
1098	Sy454	Humming	VOX	121	1	
1099	Sy455	SynVox	VOX	121	0	55
1100	Sy456	Analog Voice	VOX	121	1	
1101	Sy457	Square Wave	HLD	121	0	81
1102	Sy458	MG Square	HLD	121	1	
1103	Sy459	2600 Sine	HLD	121	2	
1104	Sy460	Saw Wave	HLD	121	0	82
1105	Sy461	OB2 Saw	HLD	121	1	
1106	Sy462	Doctor Solo	HLD	121	2	
1107	Sy463	Natural Lead	HLD	121	3	
1108	Sy464	SequencedSaw	HLD	121	4	
1109	Sy465	Syn.Calliope	SLD	121	0	83
1110	Sy466	Chiffer Lead	SLD	121	0	84
1111	Sy467	Charang	HLD	121	0	85
1112	Sy468	Wire Lead	HLD	121	1	
1113	Sy469	Solo Vox	SLD	121	0	86
1114	Sy470	5th Saw Wave	HLD	121	0	87
1115	Sy471	Bass & Lead	HLD	121	0	88
1116	Sy472	Delayed Lead	HLD	121	1	
1117	Sy473	Fantasia	SYN	121	0	89
1118	Sy474	Warm Pad	SPD	121	0	90
1119	Sy475	Sine Pad	SPD	121	1	
1120	Sy476	Polysynth	SYN	121	0	91
1121	Sy477	Space Voice	VOX	121	0	92
1122	Sy478	Itopia	VOX	121	1	
1123	Sy479	Bowed Glass	SPD	121	0	93
1124	Sy480	Metal Pad	BPD	121	0	94
1125	Sy481	Halo Pad	BPD	121	0	95
1126	Sy482	Sweep Pad	SPD	121	0	96
1127	Sy483	Ice Rain	SYN	121	0	97
1128	Sy484	Soundtrack	SPD	121	0	98
1129	Sy485	Brightness	SYN	121	0	101
1130	Sy486	Goblin	PLS	121	0	102
1131	Sy487	Echo Drops	BPD	121	0	103
1132	Sy488	Echo Bell	BPD	121	1	
1133	Sy489	Echo Pan	BPD	121	2	
1134	Sy490	Star Theme	BPD	121	0	104
1135	Sy491	Breath Noise	FX	121	0	122

No.	Tone Name	Category	MSB	LSB	PC
1136	Sy492	Fl.Key Click	FX	121	1

WORLD/OTHER

BRAZIL (BRA)

No.	Tone Name	Category	MSB	LSB	PC	
1137	Wr001	Nice Piano	ETH	087	071	046
1138	Wr002	MIDled Grand	ETH	087	071	047
1139	Wr003	West Coast	ETH	087	071	048
1140	Wr004	JV EP+	ETH	087	071	049
1141	Wr005	80's FM	ETH	087	071	050
1142	Wr006	AllSkate!SRX	ETH	087	071	051
1143	Wr007	Blues Perc	ETH	087	071	052
1144	Wr008	Perky Twin B	ETH	087	071	053
1145	Wr009	Rotary Organ	ETH	087	071	054
1146	Wr010	ParisRomance	ETH	087	071	055
1147	Wr011	Acc.Master	ETH	087	071	056
1148	Wr012	Bandoneon 2	ETH	087	071	057
1149	Wr013	Ac.Gtrs SRX	ETH	087	071	058
1150	Wr014	X Brs Sect 1	ETH	087	071	059
1151	Wr015	J-Pop Brs GW	ETH	087	071	060
1152	Wr016	DC Tri GW	ETH	087	071	061
1153	Wr017	2600 Sine GW	ETH	087	071	062
1154	Wr018	P5 Sync Lead	ETH	087	071	063
1155	Wr019	SuperSaws	ETH	087	071	064
1156	Wr020	Attack! Pad	ETH	087	071	065

CHINA (CHN)

No.	Tone Name	Category	MSB	LSB	PC	
1157	Wr021	Erhu/Vib	ETH	087	071	066
1158	Wr022	Pipa/Trem	ETH	087	071	067
1159	Wr023	Guzhng/Trm	ETH	087	071	068
1160	Wr024	Qudi/Orn	ETH	087	071	069
1161	Wr025	Xiao/Orn	ETH	087	071	070
1162	Wr026	Suona /3	ETH	087	071	071
1163	Wr027	Xun/Orn	ETH	087	071	072
1164	Wr028	Matouqin/4 3	ETH	087	071	073
1165	Wr029	Dumbra/Strum	ETH	087	071	074
1166	Wr030	Bawu/3 2	ETH	087	071	075

INDIA (IND)

No.	Tone Name	Category	MSB	LSB	PC	
1167	Wr031	Harmonium 1	ETH	087	071	076
1168	Wr032	Harmonium 2	ETH	087	071	077
1169	Wr033	Harmonium 3	ETH	087	071	078
1170	Wr034	Harmonium LS	ETH	087	071	079
1171	Wr035	D.Accordion	ETH	087	071	080
1172	Wr036	Acc.de Paris	ETH	087	071	081
1173	Wr037	Eastern Trio	ETH	087	071	082
1174	Wr038	New Delhi	ETH	087	071	083
1175	Wr039	Sorgho Field	ETH	087	071	084
1176	Wr040	Sitar XV	ETH	087	071	085
1177	Wr041	Sitar GW	ETH	087	071	086
1178	Wr042	Drone Sitar	ETH	087	071	087
1179	Wr043	SitarGlisSRX	ETH	087	071	088
1180	Wr044	Go2India /C2	ETH	087	071	089
1181	Wr045	Sarod	ETH	087	071	090
1182	Wr046	ChoChungRuan	ETH	087	071	091
1183	Wr047	HamrDulcimer	ETH	087	071	092
1184	Wr048	Dulcimer	ETH	087	071	093
1185	Wr049	Santur LS	ETH	087	071	094
1186	Wr050	Santur 2	ETH	087	071	095
1187	Wr051	Santur+trm	ETH	087	071	096

Tone List

No.	Tone Name	Category	MSB	LSB	PC	
1188	Wr052	Oygur/Trem	ETH	087	071	097
1189	Wr053	Warm VibesLS	ETH	087	071	098
1190	Wr054	Strings LS	ETH	087	071	099
1191	Wr055	Stage Str LS	ETH	087	071	100
1192	Wr056	Str+Choir 1	ETH	087	071	101
1193	Wr057	Doos	ETH	087	071	102
1194	Wr058	Mmmms	ETH	087	071	103
1195	Wr059	Chorus LS	ETH	087	071	104
1196	Wr060	Qu Di&Flute	ETH	087	071	105
1197	Wr061	Qu Di Vibro	ETH	087	071	106
1198	Wr062	Flute+1octLS	ETH	087	071	107
1199	Wr063	Alto mp	ETH	087	071	108
1200	Wr064	Alto Sax GW	ETH	087	071	109
1201	Wr065	Alto Sax LS	ETH	087	071	110
1202	Wr066	Suona	ETH	087	071	111
1203	Wr067	D-50 Stack	ETH	087	071	112
1204	Wr068	Fantasia JV	ETH	087	071	113
1205	Wr069	Heavenals	ETH	087	071	114
1206	Wr070	Wave Bells	ETH	087	071	115
1207	Wr071	Pretty Bells	ETH	087	071	116
1208	Wr072	Morning Lite	ETH	087	071	117
1209	Wr073	Prefab Chime	ETH	087	071	118
1210	Wr074	Stacc.Heaven	ETH	087	071	119
1211	Wr075	WindBellPad	ETH	087	071	120
1212	Wr076	Vintage Call	ETH	087	071	121
1213	Wr077	260 & JUNO	ETH	087	071	122
1214	Wr078	Wire Pad GW	ETH	087	071	123
1215	Wr079	Wire Pad XP	ETH	087	071	124
1216	Wr080	Far East XP	ETH	087	071	125
1217	Wr081	Been LS	ETH	087	071	126
1218	Wr082	RajasthanILS	ETH	087	071	127
1219	Wr083	Sheng Lead	ETH	087	071	128
1220	Wr084	Suona Lead	ETH	087	072	001
1221	Wr085	ErHu SynLead	ETH	087	072	002
1222	Wr086	RhythmicSaw	ETH	087	072	003
1223	Wr087	Blade Racer	ETH	087	072	004
1224	Wr088	Aero Insect	ETH	087	072	005
1225	Wr089	Helium Queen	ETH	087	072	006
1226	Wr090	Sci-Fi FX x4	ETH	087	072	007
1227	Wr091	Acid Copter	ETH	087	072	008
1228	Wr092	Plutonium	ETH	087	072	009
1229	Wr093	Creation	ETH	087	072	010
1230	Wr094	118:TablaByP	ETH	087	072	011
1231	Wr095	92:DholakPh	ETH	087	072	012
1232	Wr096	120:Dhol Ph	ETH	087	072	013

INDONESIA (IDN)

No.	Tone Name	Category	MSB	LSB	PC	
1233	Wr097	Fat Analog	ETH	087	072	014
1234	Wr098	Tech Bass	ETH	087	072	015
1235	Wr099	BigOrchestra	ETH	087	072	016
1236	Wr100	Analog Lead	ETH	087	072	017
1237	Wr101	Tech Rave	ETH	087	072	018
1238	Wr102	Basichord	ETH	087	072	019
1239	Wr103	Bs/Pno+Brs	ETH	087	072	020
1240	Wr104	Psycho EP	ETH	087	072	021
1241	Wr105	D50 NyAtmos	ETH	087	072	022
1242	Wr106	D50 Pizagogo	ETH	087	072	023
1243	Wr107	D50 Stack	ETH	087	072	024
1244	Wr108	D50 Fantasia	ETH	087	072	025
1245	Wr109	D50 Stac_Hvn	ETH	087	072	026
1246	Wr110	D50 FuturePd	ETH	087	072	027
1247	Wr111	D50 DigiNDnc	ETH	087	072	028
1248	Wr112	Film Octaves	ETH	087	072	029
1249	Wr113	JP8.Strings	ETH	087	072	030
1250	Wr114	ORBit Pad	ETH	087	072	031
1251	Wr115	SynthBrs2 GS	ETH	087	072	032
1252	Wr116	BlowAltoVib	ETH	087	072	033

No.	Tone Name	Category	MSB	LSB	PC	
1253	Wr117	Edye Boost	ETH	087	072	034

ISRAEL (ISR)

No.	Tone Name	Category	MSB	LSB	PC	
1254	Wr118	Musette tun	ETH	087	072	035
1255	Wr119	Musette det1	ETH	087	072	036
1256	Wr120	Musette det2	ETH	087	072	037
1257	Wr121	Master1	ETH	087	072	038
1258	Wr122	Master2	ETH	087	072	039
1259	Wr123	Jazz Accord	ETH	087	072	040
1260	Wr124	Bandoneon1	ETH	087	072	041
1261	Wr125	Bandoneon2	ETH	087	072	042
1262	Wr126	Bs/Musettun	ETH	087	072	043
1263	Wr127	Bs/Musettet1	ETH	087	072	044
1264	Wr128	Bs/Musettet2	ETH	087	072	045
1265	Wr129	Bs/Master1	ETH	087	072	046
1266	Wr130	Bs/Master2	ETH	087	072	047
1267	Wr131	Bs/JazzAccrd	ETH	087	072	048
1268	Wr132	Bs/Bandneon1	ETH	087	072	049
1269	Wr133	Bs/Bandneon2	ETH	087	072	050

KOREA (KOR)

No.	Tone Name	Category	MSB	LSB	PC	
1270	Wr134	Player's EP	ETH	087	072	051
1271	Wr135	Organ 1 XP	ETH	087	072	052
1272	Wr136	ChurchOrg XP	ETH	087	072	053
1273	Wr137	St.Strings	ETH	087	072	054
1274	Wr138	Soft Strings	ETH	087	072	055
1275	Wr139	Slow Str XP	ETH	087	072	056
1276	Wr140	Trumpet RD	ETH	087	072	057
1277	Wr141	Trumpet 2	ETH	087	072	058
1278	Wr142	Brass 1 RD	ETH	087	072	059
1279	Wr143	R&R Brass	ETH	087	072	060
1280	Wr144	SessionBrass	ETH	087	072	061
1281	Wr145	Alto Sax RD	ETH	087	072	062
1282	Wr146	Tenor Sax RD	ETH	087	072	063

PHILIPPINES (PHL)

No.	Tone Name	Category	MSB	LSB	PC	
1283	Wr147	Pure EP JU	ETH	087	072	064
1284	Wr148	SA EPiano JU	ETH	087	072	065
1285	Wr149	88StgGrandJU	ETH	087	072	066
1286	Wr150	Full Str JU	ETH	087	072	067
1287	Wr151	Jazz Scat JU	ETH	087	072	068

SOUTH AFRICA (ZAF)

No.	Tone Name	Category	MSB	LSB	PC	
1288	Wr152	South Africa	ETH	087	072	069
1289	Wr153	FM-777 JU	ETH	087	072	070
1290	Wr154	SC Marimba	ETH	087	072	071
1291	Wr155	Ethno KeysFS	ETH	087	072	072
1292	Wr156	N.Kalimba JU	ETH	087	072	073
1293	Wr157	Smoky Org JU	ETH	087	072	074
1294	Wr158	Perc OrganJU	ETH	087	072	075
1295	Wr159	Atk Flute	ETH	087	072	076
1296	Wr160	FS Flute	ETH	087	072	077
1297	Wr161	HimalayaP FS	ETH	087	072	078
1298	Wr162	Alto Sax FS	ETH	087	072	079
1299	Wr163	JP8000 BrsFS	ETH	087	072	080
1300	Wr164	Jump BrassFG	ETH	087	072	081

THAILAND (THA)

No.	Tone Name	Category	MSB	LSB	PC	
1301	Wr165	D-50 Organ	ETH	087	072	082
1302	Wr166	Angklung	ETH	087	072	083
1303	Wr167	Khaen	ETH	087	072	084
1304	Wr168	Khim	ETH	087	072	085
1305	Wr169	Klui	ETH	087	072	086
1306	Wr170	Pin 1	ETH	087	072	087
1307	Wr171	Pin 2	ETH	087	072	088
1308	Wr172	Pin 3	ETH	087	072	089
1309	Wr173	Ponglang	ETH	087	072	090
1310	Wr174	Ranad	ETH	087	072	091
1311	Wr175	Sor	ETH	087	072	092
1312	Wr176	Vode	ETH	087	072	093
1313	Wr177	Blow Tenor	ETH	087	072	094

TURKEY (TUR)

No.	Tone Name	Category	MSB	LSB	PC	
1314	Wr178	SA Dnc PnoJU	ETH	087	072	095
1315	Wr179	Stage EP	ETH	087	072	096
1316	Wr180	Super Wurly	ETH	087	072	097
1317	Wr181	Tine EP JU	ETH	087	072	098
1318	Wr182	R&B Organ JU	ETH	087	072	099
1319	Wr183	Perc Organ	ETH	087	072	100
1320	Wr184	Elk-Baglama	ETH	087	072	101
1321	Wr185	Aks-Baglama	ETH	087	072	102
1322	Wr186	UD	ETH	087	072	103
1323	Wr187	Kanun	ETH	087	072	104
1324	Wr188	JP StringsJU	ETH	087	072	105
1325	Wr189	JP Strings 2	ETH	087	072	106
1326	Wr190	JupiterMv JU	ETH	087	072	107
1327	Wr191	G.Keman	ETH	087	072	108
1328	Wr192	Vib-Zurna-A	ETH	087	072	109
1329	Wr193	Flugel HrnJU	ETH	087	072	110
1330	Wr194	Soft Tb JU	ETH	087	072	111
1331	Wr195	Solo Bone JU	ETH	087	072	112
1332	Wr196	TR-Klarnet	ETH	087	072	113
1333	Wr197	FolkClarinet	ETH	087	072	114
1334	Wr198	StackTp S.JU	ETH	087	072	115
1335	Wr199	Follow Me	ETH	087	072	116
1336	Wr200	Clean? JU	ETH	087	072	117
1337	Wr201	Pure SinLD 1	ETH	087	072	118
1338	Wr202	Theramax	ETH	087	072	119
1339	Wr203	Tristar FG	ETH	087	072	120
1340	Wr204	Solid Pluck	ETH	087	072	121
1341	Wr205	WaspySynthJU	ETH	087	072	122
1342	Wr206	DigitalessJU	ETH	087	072	123
1343	Wr207	Bustranza JU	ETH	087	072	124
1344	Wr208	GAIA A-7Poly	ETH	087	072	125
1345	Wr209	GAIA F-3Trns	ETH	087	072	126
1346	Wr210	Packfan	ETH	087	072	127
1347	Wr211	80s Poly	ETH	087	072	128
1348	Wr212	Cue Tip FG	ETH	087	073	001
1349	Wr213	WiredSynthFG	ETH	087	073	002
1350	Wr214	GAIA A-1 Bs	ETH	087	073	003

VIET NAM (VNM)

No.	Tone Name	Category	MSB	LSB	PC	
1351	Wr215	JP8 PulseLd1	ETH	087	073	004
1352	Wr216	Dist TB 2	ETH	087	073	005
1353	Wr217	Short Bs 1	ETH	087	073	006
1354	Wr218	Short Bs 2	ETH	087	073	007
1355	Wr219	Short Bs 3	ETH	087	073	008
1356	Wr220	Monster Bs 1	ETH	087	073	009
1357	Wr221	Monster Bs 7	ETH	087	073	010
1358	Wr222	SuperSawBs10	ETH	087	073	011
1359	Wr223	Slap Bass JP	ETH	087	073	012

No.	Tone Name	Category	MSB	LSB	PC	
1360	Wr224	Dist.Fing JU	ETH	087	073	013

LATIN AMERICA (LAS)

No.	Tone Name	Category	MSB	LSB	PC	
1361	Wr225	FullDraw GW	ETH	087	073	014
1362	Wr226	Steierische	ETH	087	073	015
1363	Wr227	G-Accord 1	ETH	087	073	016
1364	Wr228	G-Accord 2	ETH	087	073	017
1365	Wr229	G-Accord 3	ETH	087	073	018
1366	Wr230	C-Accord A1	ETH	087	073	019
1367	Wr231	C-Accord A2	ETH	087	073	020
1368	Wr232	C-Accord A3	ETH	087	073	021
1369	Wr233	C-Accord N1	ETH	087	073	022
1370	Wr234	C-Accord N2	ETH	087	073	023
1371	Wr235	E-Accord 1	ETH	087	073	024
1372	Wr236	E-Accord 2	ETH	087	073	025
1373	Wr237	BajoSxt /2	ETH	087	073	026
1374	Wr238	BajoSxt /3	ETH	087	073	027
1375	Wr239	BajoSxt Mt	ETH	087	073	028
1376	Wr240	Charango Dn	ETH	087	073	029
1377	Wr241	Charango Up	ETH	087	073	030
1378	Wr242	Chrng Oct Dn	ETH	087	073	031
1379	Wr243	Chrng Oct Up	ETH	087	073	032
1380	Wr244	Charango /C	ETH	087	073	033
1381	Wr245	Chrng Oct /C	ETH	087	073	034
1382	Wr246	Charango D&U	ETH	087	073	035
1383	Wr247	ChrngOct D&U	ETH	087	073	036
1384	Wr248	Guitarron	ETH	087	073	037
1385	Wr249	Guitarr Oct	ETH	087	073	038
1386	Wr250	Banda ClaVib	ETH	087	073	039
1387	Wr251	Banda ClaStc	ETH	087	073	040
1388	Wr252	MariTp Vb /2	ETH	087	073	041
1389	Wr253	MariTp Vb /3	ETH	087	073	042
1390	Wr254	MariTp Stac	ETH	087	073	043
1391	Wr255	CmbiTp Vb /4	ETH	087	073	044
1392	Wr256	Banda Tp Vib	ETH	087	073	045
1393	Wr257	Banda Tp Stc	ETH	087	073	046
1394	Wr258	Banda TbnVib	ETH	087	073	047
1395	Wr259	Banda TbnStc	ETH	087	073	048
1396	Wr260	Banda Tuba	ETH	087	073	049
1397	Wr261	BandaTubaStc	ETH	087	073	050
1398	Wr262	Switch Fall	ETH	087	073	051
1399	Wr263	Mariachi Tp1	ETH	087	073	052
1400	Wr264	Latin Trumpt	ETH	087	073	053
1401	Wr265	Romantic Tp.	ETH	087	073	054
1402	Wr266	Snake Eyes	ETH	087	073	055
1403	Wr267	Shake Tp.	ETH	087	073	056
1404	Wr268	Tp. Rom/Mar	ETH	087	073	057
1405	Wr269	Tp. Mar/Shk	ETH	087	073	058
1406	Wr270	SuperTnr SRX	ETH	087	073	059
1407	Wr271	RS Alto Sax	ETH	087	073	060
1408	Wr272	Sugar Keys	ETH	087	073	061
1409	Wr273	SL Fantasia	ETH	087	073	062
1410	Wr274	SL LivingCal	ETH	087	073	063
1411	Wr275	SL D50Synth	ETH	087	073	064
1412	Wr276	SL D50Brass	ETH	087	073	065
1413	Wr277	SLSoundTrack	ETH	087	073	066

OTHER

* Wr318–Wr330 are GM/GM2 tones.

No.	Tone Name	Category	MSB	LSB	PC	
1414	Wr278	Gamelan	ETH	087	073	067
1415	Wr279	Anklung	ETH	087	073	068
1416	Wr280	Gambus	ETH	087	073	069
1417	Wr281	Sitar on C	PLK	087	073	070
1418	Wr282	JUNO Sitar 1	PLK	087	073	071
1419	Wr283	JUNO Sitar 2	PLK	087	073	072

Tone List

No.	Tone Name	Category	MSB	LSB	PC	
1420	Wr284	Sitar Baby	PLK	087	073	073
1421	Wr285	Neo Sitar	PLK	087	073	074
1422	Wr286	SaraswatiRvr	PLK	087	073	075
1423	Wr287	Teky Drop	PLK	087	073	076
1424	Wr288	TroubadorEns	PLK	087	073	077
1425	Wr289	Elec Sitar	PLK	087	073	078
1426	Wr290	Pat is away	PLK	087	073	079
1427	Wr291	Nice Kalimba	PLK	087	073	080
1428	Wr292	Quiet River	PLK	087	073	081
1429	Wr293	Aerial Harp	PLK	087	073	082
1430	Wr294	Harpiness	PLK	087	073	083
1431	Wr295	Skydiver	PLK	087	073	084
1432	Wr296	Jamisen	PLK	087	073	085
1433	Wr297	JUNO Koto	PLK	087	073	086
1434	Wr298	Monsoon	PLK	087	073	087
1435	Wr299	Bend Koto	PLK	087	073	088
1436	Wr300	JUNO Banjo	FRT	087	073	089
1437	Wr301	Pan Pipes	ETH	087	073	090
1438	Wr302	Andes Mood	ETH	087	073	091
1439	Wr303	LongDistance	ETH	087	073	092
1440	Wr304	Ambi Shaku	ETH	087	073	093
1441	Wr305	HimalayaPipe	ETH	087	073	094
1442	Wr306	Ethnic Lead	ETH	087	073	095
1443	Wr307	Lochscape	ETH	087	073	096
1444	Wr308	PipeDream	ETH	087	073	097
1445	Wr309	Angel Pipes	ETH	087	073	098
1446	Wr310	Far East	ETH	087	073	099
1447	Wr311	Wired Synth	ETH	087	073	100
1448	Wr312	4DaCommonMan	ETH	087	073	101
1449	Wr313	Orgaenia	ETH	087	073	102
1450	Wr314	Sleeper	ETH	087	073	103
1451	Wr315	Ice Palace	ETH	087	073	104
1452	Wr316	Story Harp	ETH	087	073	105
1453	Wr317	LostParadise	ETH	087	073	106
1454	Wr318	Santur	PLK	121	0	16
1455	Wr319	Harp	PLK	121	0	47
1456	Wr320	Yang Qin	PLK	121	1	
1457	Wr321	Shakuhachi	ETH	121	0	78
1458	Wr322	Sitar	PLK	121	0	105
1459	Wr323	Sitar 2	PLK	121	1	
1460	Wr324	Banjo	FRT	121	0	106
1461	Wr325	Shamisen	PLK	121	0	107
1462	Wr326	Koto	PLK	121	0	108
1463	Wr327	Taisho Koto	PLK	121	1	
1464	Wr328	Kalimba	PLK	121	0	109
1465	Wr329	Bagpipe	ETH	121	0	110
1466	Wr330	Shanai	ETH	121	0	112

No.	Tone Name	Category	MSB	LSB	PC	
1484	Dr018	Latin Menu3		086	064	018
1485	Dr019	LatinPerc'06		086	064	019
1486	Dr020	GM2 STANDARD		120	0	001
1487	Dr021	GM2 ROOM		120	0	009
1488	Dr022	GM2 POWER		120	0	017
1489	Dr023	GM2 ELECTRIC		120	0	025
1490	Dr024	GM2 ANALOG		120	0	026
1491	Dr025	GM2 JAZZ		120	0	033
1492	Dr026	GM2 BRUSH		120	0	041
1493	Dr027	GM2 ORCHSTRA		120	0	049
1494	Dr028	GM2 SFX		120	0	057
1495	Dr029	Timpani+Low	PRC	087	073	107
1496	Dr030	Timpani Roll	PRC	087	073	108
1497	Dr031	Bass Drum	PRC	087	073	109
1498	Dr032	Ambidextrous	SFX	087	073	110
1499	Dr033	En-co-re	SFX	087	073	111
1500	Dr034	Mobile Phone	SFX	087	073	112
1501	Dr035	ElectroDisco	BTS	087	073	113
1502	Dr036	Groove 007	BTS	087	073	114
1503	Dr037	In Da Groove	BTS	087	073	115
1504	Dr038	Sweet 80s	BTS	087	073	116
1505	Dr039	Auto Trance2	BTS	087	073	117
1506	Dr040	JUNO Pop	BTS	087	073	118
1507	Dr041	Compusonic 1	BTS	087	073	119
1508	Dr042	Compusonic 2	BTS	087	073	120
1509	Dr043	Mix Drum 1	DRM	087	073	121
1510	Dr044	Mix Drum 2	DRM	087	073	122
1511	Dr045	Timpani	PRC	121	0	48
1512	Dr046	Agogo	PRC	121	0	114
1513	Dr047	Woodblock	PRC	121	0	116
1514	Dr048	Castanets	PRC	121	1	
1515	Dr049	Taiko	PRC	121	0	117
1516	Dr050	Concert BD	PRC	121	1	
1517	Dr051	Melo. Tom 1	PRC	121	0	118
1518	Dr052	Melo. Tom 2	PRC	121	1	
1519	Dr053	Synth Drum	PRC	121	0	119
1520	Dr054	808 Tom	PRC	121	1	
1521	Dr055	Elec Perc	PRC	121	2	
1522	Dr056	Reverse Cym.	PRC	121	0	120
1523	Dr057	Seashore	SFX	121	0	123
1524	Dr058	Rain	SFX	121	1	
1525	Dr059	Thunder	SFX	121	2	
1526	Dr060	Wind	SFX	121	3	
1527	Dr061	Stream	SFX	121	4	
1528	Dr062	Bubble	SFX	121	5	
1529	Dr063	Bird	SFX	121	0	124
1530	Dr064	Dog	SFX	121	1	
1531	Dr065	Horse-Gallop	SFX	121	2	
1532	Dr066	Bird 2	SFX	121	3	
1533	Dr067	Telephone 1	SFX	121	0	125
1534	Dr068	Telephone 2	SFX	121	1	
1535	Dr069	DoorCreaking	SFX	121	2	
1536	Dr070	Door	SFX	121	3	
1537	Dr071	Scratch	SFX	121	4	
1538	Dr072	Wind Chimes	SFX	121	5	
1539	Dr073	Helicopter	SFX	121	0	126
1540	Dr074	Car-Engine	SFX	121	1	
1541	Dr075	Car-Stop	SFX	121	2	
1542	Dr076	Car-Pass	SFX	121	3	
1543	Dr077	Car-Crash	SFX	121	4	
1544	Dr078	Siren	SFX	121	5	
1545	Dr079	Train	SFX	121	6	
1546	Dr080	Jetplane	SFX	121	7	
1547	Dr081	Starship	SFX	121	8	
1548	Dr082	Burst Noise	SFX	121	9	
1549	Dr083	Applause	SFX	121	0	127
1550	Dr084	Laughing	SFX	121	1	
1551	Dr085	Screaming	SFX	121	2	
1552	Dr086	Punch	SFX	121	3	

DRUMS/FX

* Dr020–Dr028, Dr045–Dr092 are GM/GM2 tones.

No.	Tone Name	Category	MSB	LSB	PC	
1467	Dr001	Pop Kit 1		086	064	001
1468	Dr002	Rock Kit		086	064	002
1469	Dr003	Brush Jz Kit		086	064	003
1470	Dr004	HipHop Kit		086	064	004
1471	Dr005	R&B Kit		086	064	005
1472	Dr006	Dance Kit 1		086	064	006
1473	Dr007	Dance Kit 2		086	064	007
1474	Dr008	Dance Kit 3		086	064	008
1475	Dr009	Pop Kit 2		086	064	009
1476	Dr010	Dance Kit 4		086	064	010
1477	Dr011	Nu India Kit		086	064	011
1478	Dr012	Indomix Kit		086	064	012
1479	Dr013	BK StudioKt1		086	064	013
1480	Dr014	BK StudioKt2		086	064	014
1481	Dr015	LatinDrmKit		086	064	015
1482	Dr016	Latin Menu1		086	064	016
1483	Dr017	Latin Menu2		086	064	017

No.	Tone Name	Category	MSB	LSB	PC	
1553	Dr087	Heart Beat	SFX	121	4	
1554	Dr088	Footsteps	SFX	121	5	
1555	Dr089	Gun Shot	SFX	121	0	128
1556	Dr090	Machine Gun	SFX	121	1	
1557	Dr091	Lasergun	SFX	121	2	
1558	Dr092	Explosion	SFX	121	3	

SAMPLE

No.	Tone Name	Category	MSB	LSB	PC	
1559	Sp001	NylonGtr E4	CMB	087	073	123
1560	Sp002	Pemade C5	CMB	087	073	124
1561	Sp003	Shankh G#4	CMB	087	073	125
1562	Sp004	RSS SpinnrC4	CMB	087	073	126
1563	Sp005	Come On! C4	CMB	087	073	127
1564	Sp006	102:PhraseC4	CMB	087	073	128

Performance List

No.	Performance Name
001	Bass / Piano
002	Piano & Str
003	GrandStrings
004	3-Split Perf
005	Real D-50
006	SatelliteGtr
007	SynStr/SawLd
008	FolkClarinet
009	Blues Perc
010	Air Garden
011	Notre-Dame
012	Big & Proud
013	Whale Pad
014	GM2 Template
015	Seq;Template
016	Init Perform

Drum Kit Tone List

	Dr001 Pop Kit 1	Dr002 Rock Kit	Dr003 Brush Jz Kit	Dr004 HipHop Kit	Dr005 R&B Kit
21					
22					
23					
C1 24					
25					
26					
27					
28					
29					
30					
31	Kick1	Kick1	Kick1	Analog Kick1	Mix Kick1
32	Snare Ghost1	Snare Ghost1	Snare Ghost	Analog Kick2	Mix Kick2
33	Kick2	Kick2	Kick2	Mix Kick1	Mix Kick3
34	Pedal Hihat	Pedal Hihat	Pedal Hi-hat	Mix Kick2	Mix Kick4
35	Kick3	Power Kick1	Jazz Kick 1	Analog Kick3	Mix Kick5
C2 36					
37	Kick4	Power Kick2	Jazz Kick 2	Mix Kick3	Mix Kick6
38	Side Stick	Side Stick	Side Stick	TR808 Rim1	Soft Stick
39	Snare1	Power Snare1	Brush Slap1	Mix Snare1	Short Snare1
40	Snare Ghost2	Snare Ghost2	Jz Brsh Swsh	Mix Clap1	Mix Stick
41	Snare2	Power Snare2	Brush Slap2	Mix Snare2	Short Snare2
42	Low Tom1	Low Tom1	BrushLowTom	Mix Snare3	Short Snare3
43	Cl Hihat1	Cl Hihat1	Brush ClHH1	TR808 ClHH	Cl Hihat1
44	Low Tom2	Low Tom2	BrushMidTom1	Mix Snare4	Short Snare4
45	Cl Hihat2	Cl Hihat2	Brush ClHH2	Noise ClHH	Cl Hihat2
46	Mid Tom1	Mid Tom1	BrushMidTom2	Mix Snare5	Mix Snare1
47	Op Hihat	Op Hihat	Brush OpHH	TR808 OpHH	Op Hihat
48	Mid Tom2	Mid Tom2	BrushMidTom2	Mix Snare6	Mix Snare2
C3 49					
50	High Tom1	High Tom1	Brush HiTom	Syn Swt Atk1	Mix Snare3
51	CrashCymbal1	CrashCymbal1	CrashCymbal1	TR808 Cym1	TR808 Cym1
52	High Tom2	High Tom2	Brush HiTom	MG Attack	Mix Snare4
53	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	TR808 Cym2	TR808 Cym2
54	China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
55	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Rock Rd Edge	Rock Rd Edge
56	Tambourine	Tambourine	Tambourine	Tambourine1	Tambourine1
57	SplashCymbal	SplashCymbal	SplashCymbal	Mix Crash1	Mix Crash1
58	Cowbell	Cowbell	Cowbell	Mix Hat	Mix Hat
59	CrashCymbal2	CrashCymbal2	CrashCymbal2	Mix Crash2	Mix Crash2
60	Vibraslap	Vibraslap	Vibraslap	Syn Swt Atk2	Syn Swt Atk
61	Ride Cymbal3	Ride Cymbal3	Ride Cymbal3	TR808 Kick1	TR808 Kick1
C4 62					
63	High Bongo1	High Bongo1	High Bongo	TR808 Kick2	TR808 Kick2
64	Low Bongo1	Low Bongo1	Low Bongo	TR808 Rim2	TR808 Rim
65	Conga Slap	Conga Slap	MtHigh Conga	TR808 Snare1	TR808 Snare1
66	OpenHi Conga	OpenHi Conga	OpHigh Conga	TR808 Clap1	TR808 Clap1
67	Low Conga1	Low Conga1	Low Conga	TR808 Snare2	TR808 Snare2
68	High Timbale	High Timbale	High Timbale	TR808 Tom1	TR808 Tom1
69	Low Timbale	Low Timbale	Low Timbale	TR808 ClHH	TR808 ClHH
70	High Agogo	High Agogo	High Agogo	TR808 Tom2	TR808 Tom2
71	Low Agogo	Low Agogo	Low Agogo	Noise ClHH	Noise ClHH
72	Cabasa	Cabasa	Cabasa	TR808 Tom3	TR808 Tom3
73	Maracas	Maracas	Maracas	TR808 OpHH	TR808 OpHH
74	ShortWhistle	ShortWhistle	Jazz Kick 1	TR808 Tom4	TR808 Tom4
C5 75					
76	Long Whistle	Long Whistle	Jazz Kick 2	TR808 Tom5	TR808 Tom5
77	Short Guiro	Short Guiro	Side Stick	Scratch1	Scratch1
78	Long Guiro	Long Guiro	Jazz Snare1	TR808 Tom6	TR808 Tom6
79	Claves	Claves	Sft Snr Gst	Scratch2	Scratch2
80	Hi WoodBlock	Hi WoodBlock	Jazz Snare2	Hand Clap1	Hand Clap1
81	LowWoodBlock	LowWoodBlock	Low Tom	Hand Clap2	Hand Clap2
82	Mute Cuica	Mute Cuica	Cl Hihat1	TR808 Clap2	TR808 Clap2
83	Open Cuica	Open Cuica	Mid Tom1	Cabasa	Cabasa
84	MuteTriangle	MuteTriangle	Cl Hihat2	Shaker1	Shaker1
85	OpenTriangle	OpenTriangle	Mid Tom2	Tambourine2	Tambourine2
86	Shaker	Shaker	Op Hihat	Shaker2	Shaker2
87	Castanet	Castanet	Mid Tom2	Castanet	Castanet
C6 88					
89	High Bongo2	High Bongo2	High Tom	High Bongo	High Bongo
90	MtHigh Conga	MtHigh Conga	CrashCymbal1	MtHigh Conga	MtHigh Conga
91	Low Bongo2	Low Bongo2	High Tom	Low Bongo1	Low Bongo1
92	Low Bongo3	Low Bongo3	Ride Cymbal1	Low Bongo2	Low Bongo2
93	Low Conga2	Low Conga2	China Cymbal	Op Low Conga	Op Low Conga
94	Low Tom3	Low Tom3	Low Tom3	Low Tom1	Low Tom1
95	Low Tom4	Low Tom4	Low Tom4	Low Tom2	Low Tom2
96	Mix Kick1	Mix Kick1	Claves	Mix Kick4	Mix Kick7
97	Mix Kick2	Mix Kick2	Hi WoodBlock	Mix Kick5	Mix Kick8
98	Mix Kick3	Mix Kick3	LowWoodBlock	TR909 Snare	Stream
99	Mix Kick4	Mix Kick4	MuteTriangle	Syn Burst Nz	Bubble
100	Mix Nz1	Mix Nz1	OpenTriangle	Digi Breath	Train
C7 101					
102	Mix Nz2	Mix Nz2	Shaker	Mix Breath	Wind Chime
103	Mix Nz3	Mix Nz3	Castanet	Wide Shaker	Syn Back Nz1
104	Wind Chime	Wind Chime	Wind Chime	JD Tuba Slap	Syn Back Nz2
105	Hand Clap1	Hand Clap1	Hand Clap 1	Hand Clap3	Hand Clap3
106	Hand Clap2	Hand Clap2	Hand Clap 2	Hand Clap4	Hand Clap4
107				Door Creak	
108				Vint.Phone	
C8				Polish Kick	

Drum Kit Tone List

	Dr006 Dance Kit 1	Dr007 Dance Kit 2	Dr008 Dance Kit 3	Dr009 Pop Kit 2	Dr010 Dance Kit 4
21					
22					
23					
C1					
24					
25					
26					
27					
28	TR808 Kick	SH32 Kick1	TR909 Kick1		TR808 Kick
29	Mix Kick1	TR909 Kick1	SH32 Kick1		Mix Kick1
30	Mix Snare1	AnalogSnare1	Snare Ghost1		Mix Snare1
31	Mix Kick2	Analog Kick1	Analog Kick	Kick1	Mix Kick2
32	Mix Snare2	TR808 Snare	TR909 Snare1	Snare Ghost1	Mix Snare2
33	Mix Kick3	SH32 Kick2	SH32 Kick2	Kick2	Mix Kick3
34	Thin CIHH	Pedal Hihat	Pedal Hihat	Pedal Hihat	Thin CIHH
35	Mix Kick4	TR909 Kick2	TR909 Kick2	Kick3	Mix Kick4
C2					
36	Mix Kick5	Analog Kick2	TR909 Kick3	Kick4	Mix Kick5
37	Mix Rim1	Synth Rim	TR808 Rim1	Side Stick	Mix Rim1
38	Analog Snare	TR909 Snare	TR909 Snare2	Snare1	Mix Snare3
39	TR808 Clap	TR808 Clap1	TR808 Clap	Snare Ghost2	TR808 Clap
40	Mix Snare3	DistNz Snare	TR909 Snare3	Snare2	Mix Snare4
41	Mix Tom1	Deep Tom1	TR808 Tom1	Low Tom1	Mix Tom1
42	Mix CIHH1	TR808 CIHH	CI Hihat1	CI Hihat1	Mix CIHH1
43	Mix Tom2	Deep Tom1	TR808 Tom2	Low Tom2	Mix Tom2
44	Mix CIHH2	TR606 OpHH	CI Hihat2	CI Hihat2	Mix CIHH2
45	Mix Tom3	Deep Tom2	TR808 Tom3	Mid Tom1	Mix Tom3
46	Op Hihat	TR808 Cym1	Op Hihat1	Op Hihat	Op Hihat
47	Mix Tom3	Deep Tom2	TR808 Tom4	Mid Tom2	Mix Tom3
C3					
48	Mix Tom4	Deep Tom3	TR808 Tom5	High Tom1	Mix Tom4
49	Crash Cymbal	TR808 OpHH	CrashCymbal1	CrashCymbal1	Crash Cymbal
50	Mix Tom4	Deep Tom3	TR808 Tom6	High Tom2	Mix Tom4
51	Rock Rd Edge	Wide Syn Cym	Ride Cymbal1	Ride Cymbal1	Rock Rd Edge
52	China Cymbal	TR808 Cym2	Rock Chash	China Cymbal	China Cymbal
53	Ride Cymbal	China Cym1	Ride Cup	Ride Cymbal2	Ride Cymbal
54	Tambourine	Castanet	Tambourine1	Tambourine	Tambourine
55	Rock Crash	TR808 Cym3	Syn Swt Atk1	SplashCymbal	Rock Crash
56	Cowbell	Syn Cowbell	Agogo Noise	Cowbell	Cowbell
57	Concert Cym	China Cym2	MG Zap1	CrashCymbal2	Concert Cym
58	Vibraslap	Syn Swt Atk1	Syn Swt Atk2	Vibraslap	Vibraslap
59	TR808 Cym	TR909 Kick3	TR909 Kick4	Ride Cymbal3	TR808 Cym
C4					
60	Bongo1	Analog Kick3	SH32 Kick3	High Bongo1	Bongo1
61	Bongo2	Syn Stick	TR808 Rim2	Low Bongo1	Bongo2
62	Bongo&Conga1	AnalogSnare2	TR808 Snare1	Conga Slap	Bongo&Conga1
63	Conga	TR808 Clap2	TR808 Clap1	OpenHi Conga	Conga
64	Bongo&Conga2	AnalogSnare3	Analog Snare	Low Conga1	Bongo&Conga2
65	TR808 Conga	Shaker1	Mid Tom1	High Timbale	TR808 Conga
66	Maracas	Syn CIHH1	Noise CIHH	Low Timbale	Maracas
67	Shaker	Shaker2	Mid Tom2	High Agogo	Shaker
68	Triangle1	Syn CIHH2	CI Hihat3	Low Agogo	Triangle1
69	Cabasa	Atmosphere1	Mid Tom3	Cabasa	Cabasa
70	Guiro	Syn OpHH	Op Hihat2	Maracas	Guiro 1
71	Street OpHH	Atmosphere2	Mid Tom4	ShortWhistle	Street OpHH
C5					
72	Scratch	Atmosphere3	Mid Tom5	Long Whistle	Scratch
73	Mix Atk1	TR808 Cym4	Rock Crash2	Short Guiro	Mix Atk1
74	MG Zap	Atmosphere4	Mid Tom6	Long Guiro	MG Zap
75	Syn Swt Atk1	Mix Ride	SplashCymbal	Claves	Syn Swt Atk1
76	Syn Swt Atk2	China Cym3	Rock Crash3	Hi WoodBlock	Syn Swt Atk2
77	Cuica Low	Rock Rd Edge	Rock Rd Edge	LowWoodBlock	Cuica Low
78	Triangle2	Syn Slap	Tambourine2	Mute Cuica	Triangle2
79	Triangle3	MG Zap1	Syn Swt Atk3	Open Cuica	Triangle3
80	Triangle4	SynVox Noise	Cowbell1	MuteTriangle	Triangle4
81	Mix Hit1	Mix Hit1	Syn Swt Atk4	OpenTriangle	Guiro 2
82	Mix Hit2	Syn Swt Atk2	Cowbell2	Shaker	Mix Hit2
83	Mix Hit3	MG Zap3	MG Zap2	Castanet	Mix Hit3
C6					
84	Wind Chime	808 Maracas	Low Bongo	High Bongo2	Wind Chime
85	Timpani Roll	TR808 Claves	MtHigh Conga	MtHigh Conga	Timpani Roll
86	Crotale	MuteTriangle	Conga Slap	Low Bongo2	Crotale
87	R8 Click	OpenTriangle	OpHigh Conga	Low Bongo3	R8 Click
88	Metro Bell	Mix Hit	Op Low Conga	Low Conga2	Metro Bell
89	DR202 Beep 1	Scratch	High Timbale	Low Tom3	MC500 Beep 1
90	DR202 Beep 2	Easy Gtr	Low Timbale	Low Tom4	MC500 Beep 2
91	Sweep Down1	Syn Bel Atk	High Agogo	Mix Kick1	Sweep Down1
92	Sweep Up	MG Attack	Low Agogo	Mix Kick2	Sweep Up
93	Sweep Down2	SynSnareRoll	Cabasa	Mix Kick3	Sweep Down2
94	Light Wood	Syn Burst Nz	Maracas	Mix Kick4	Light Wood
95	Laser	White Noise	Short Guiro	Mix Nz1	Laser
C7					
96	Low Atk	Polishing Nz	Long Guiro	Mix Nz2	Low Atk
97	Analog Kick	Long Guiro	Claves	Mix Nz3	Analog Kick
98	Old Kick	Light Wood	LowWoodBlock	Wind Chime	Old Kick
99	Mix Kick6	Light Wood	Hi WoodBlock	Hand Clap1	Mix Kick6
100	TR909 Snare	Syn Swt Atk3	MuteTriangle	Hand Clap2	TR909 Snare
101	TR808 Snare	Laugh	OpenTriangle		TR808 Snare
102	Mix Snare4	Office Phone	Castanet		Mix Snare5
103	Mix Snare5	Polish Kick	Whistle		Mix Snare6
104					
105					
106					
107					
C8					
108					

Drum Kit Tone List

	Dr011 Nu India Kit	Dr012 Indomix Kit	Dr013 BK StudioKt1	Dr014 BK StudioKt2	Dr015 LatinDrmKit
21		Kane			TimbalesHand
22		Gamelan Gong	MC-500 Beep1	MC-500 Beep1	Timbles HiMt
23		HipHop BD1	MC-500 Beep2	MC-500 Beep2	Timbles HiOp
C1		HipHop BD2	Concert SD	Concert SD	Timbles LoMt
24	25	IPopGst39mn	Snare Roll 1	Snare Roll 1	Timbles LoOp
26		Rap Snare	Finger Snap2	Finger Snap2	TmbSideStick
27		Dance Snare2	High Q	High Q	TimblesPaila
28		TR-909 Snare	Slap	Slap	SectChd m9
29		707CHH	Scratch Push	Scratch Push	SectChd Mj9
30		NewJzKik	Scratch Pull	Scratch Pull	TimbalesFil4
31		NewJzSn1	Sticks	Sticks	TimbalesFil3
32		NewJzTomLo	Reg.PHH	Reg.PHH	TimbalesFil2
33		NewRkTomMid	Hand Clap	Hand Clap	TimbalesFil1
34		NewJzTomHi	Snare Roll 2	Snare Roll 2	Dixie HH Hlf
35		PopKick_PL	Warm Kick	Warm Kick	Fat BD
C2		TR-707 BD	Hush Kick	Hush Kick	Room Kick 2
36	37	TR-707 Rim	WoodSideStk	Br.SideStk	Cross Stick2
38		PopSnareL	TitanSnr	Br.Snr 1	Maple Lo Snr
39		PopSnrGhst	T.Snr Ghst	IronSnrGst	Hand Clap 2
40		PopSnareR	T.Snr R5	Br.Snr 2	MapleSoft SN
41		PopFlrTmFl	StudioT4	StudioT4	Studio Tom 4
42		PopHiHat_U	Reg.CHH 1	Reg.CHH 1	Dixie HH Cls
43		PopFloorTm	StudioT3	StudioT3	Studio Tom 3
44		PopHiHat_S	Reg.CHH 2	Reg.CHH 2	Dixie HH Pdl
45		RockTom2Fl	StudioT3	StudioT3	Studio Tom 2
46		PopHHatOpen1	Reg.OHH	Reg.OHH	Dixie HH Opn
47		PopTom2	StudioT2	StudioT2	Studio Tom 2
C3		RockTom1Fl	StudioT2	StudioT2	Studio Tom 1
48	49	PopCrash	Crash Cym	Crash Cym	Crash Cymbal
50		PopTom1	StudioT1	StudioT1	Studio Tom 1
51		PopRide	Rock Ride	Rock Ride	Rock RdCym1
52		RockCrash1	Chinese Cym	Chinese Cym	Crash 1
53		PopRideBl	Rock Ride	Rock Ride	Bongo 1 Hi
54		Tambourine	Tambourine	Tambourine	Tambrin Hit
55		RockSplash	Splash Cym	Splash Cym	Bongo 1 Lo
56		CowBell	Cowbell	Cowbell	Cowbell Op 1
57		RockCrash2	Crash Cym	Crash Cym	BongoHiSlap1
58		Vibraslap	Vibra-slap	Vibra-slap	Cowbell 3
59		RockRide1	Rock Ride	Rock Ride	Bongo LoSlap
C4		Conga Hi Mt	StudioT4	High Bongo	Conga Hi Mt
60	61	Conga Lo Mt	Low Bongo	Low Bongo	Conga Lo Mt
62		Conga Slap	Mute HiConga	Mute HiConga	Conga Slap
63		Conga Hi Op	Open HiConga	Open HiConga	Conga Hi Op
64		CongaLoOp f	Open LoConga	Open LoConga	CongaLoOp f
65		CongaLoOp mf	High Timbale	High Timbale	Timbles HiMt
66		Bongo 1 Hi	Low Timbale	Low Timbale	Timbles LoOp
67		BongoLoOp f	High Agogo	High Agogo	Agogo 2 Hi
68		808cowbell	Low Agogo	Low Agogo	Agogo 2 Lo
69		NewShaker2	Cabasa	Cabasa	Real Cabasa2
70		808Maracas	Maracas	Maracas	Maracas 2
71		Cabasa	ShortWhistle	ShortWhistle	Maracas 3
C5		Dhol 2	Long Whistle	Long Whistle	ApitoHiShort
72	73	Dholak 1	Short Guiro	Short Guiro	ApitoLoShort
74		Dholak 2	Long Guiro	Long Guiro	Guiro Short2
75		Dholak 3	Claves	Claves	Guiro Long2
76		Dholak 4	Hi Wood Blck	Hi Wood Blck	Claves Lo 2
77		Dholak 5	Lo Wood Blck	Lo Wood Blck	Berimbau Up
78		Dholak 7	Mute Cuica	Mute Cuica	Berimbau Dn
79		Dholak 8	Open Cuica	Open Cuica	Cuica Hi 1
80		Dholak 9	MuteTriangle	MuteTriangle	Cuica Lo 2
81		Dholak Ga	OpenTriangle	OpenTriangle	Caixa Mute
82		Shaker	Shaker	Shaker	Caixa Open2
83		Dholak Tun	Jingle Bell	Jingle Bell	Caixa Rim
C6		Tabla Baya 4	Wind Chime	Wind Chime	Caixa Roll2
84	85	Tabla Baya 5	Castanets	Castanets	Cajon Rol Hi
86		Tabla BayaNa	Mute Surdo	Mute Surdo	Cajon Rol Lo
87		Tabla BayaTi	Open Surdo	Open Surdo	Surdo Mute2
88		TablaBayaTun	Applause 2	Applause 2	Surdo Open2
89		Udu Pot1 Hi			PandeiroL Hi
90		Udu Pot1 Lo			PandeiroL Lo
91		Udu Pot2 Lng			PandeiroOpen
92		Udu Pot2 Sht			PandeiroMute
93		TablaBayaSld			PandeiroL Rm
94		118:TablaByP			PandeiroL Sp
95		92:DholakPh			Quijada
C7		Dholak Na	Std.1 Snare1	Std.1 Snare1	Rainstick
96	97	OpenTriangle	Std.1 Snare2	Std.1 Snare2	Metronome 2
98		Hand Clap 21	Std 2 Snare1	Std 2 Snare1	R8 Click
99		Dholla1 Rim2	Std 2 Snare2	Std 2 Snare2	Metronome 1
100		Dholla1 Sak	Snare Drum 2	Snare Drum 2	180:LatinPt2
101	102	Dhoff 2 Dom 1	Std 1 Snare1	Std 1 Snare1	160:CgMambo
103		Dhoff 1 Rim 1	Std 1 Snare2	Std 1 Snare2	132:TmbIPtn1
104		Dhoff 1 Dom	Std Snare 3	Std Snare 3	132:AgogoPtn
105		Dhoff 1 Sak	Jazz Snare 1	Jazz Snare 1	104:Shakin'
106		Tabla1 Tak 1	Jazz Snare 2	Jazz Snare 2	
107		Tabla1 Dom 1	Room Snare 1	Room Snare 1	
C8		Tabla Fx	Room Snare 2	Room Snare 2	
108					

Drum Kit Tone List

	Dr016 Latin Menu1	Dr017 Latin Menu2	Dr018 Latin Menu3	Dr019 LatinPerc'06
21				
22				
23				
C1 24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
C2 36	Agogo 2 Hi	Cuica 3	Surdo Hard	
37	Agogo 2 Lo	Cuica Hi 1	Surdo Mute	
38	Agogo 3 Hi	Cuica Hi 2	Surdo Mute2	
39	Agogo 3 Lo	Cuica Lo 1	Surdo Open H	
40	ApitoHiShort	Cuica Lo 2	Surdo Open L	
41	ApitoLoShort	Ganza Hard	Surdo Open1	
42	Berimbau Dn	Ganza Soft	Surdo Open2	
43	Berimbau Mut	Guiro Long	Surdo Rim	
44	Berimbau Opn	Guiro Long2	Surdo Rim 2	
45	Berimbau Up	Guiro Short	Surdo Soft	
46	Bongo 1 Hi	Guiro Short2	Tamborim Mut	
47	Bongo 1 Lo	Hand Clap 2	Tamborim Opn	
C3 48	Bongo 2 Hi	MamboBell Mt	Tamborim Slp	
49	Bongo 2 Lo	MamboBell Op	TamborimMute	
50	Bongo Hi Hrd	Maracas 2	TamborimOpen	
51	Bongo HiOp f	MaracasUpDwn	TamborimRim	
52	Bongo Lo Hrd	MtIGuiroLng	TamborimRoll	
53	Bongo Lo Sft	MtIGuiroSht	Tambrin Hit	
54	Bongo LoOp f	PandeiroCrsh	TambrinShake	
55	Bongo LoOpmf	PandeiroHit	Timbale Hi	
56	Bongo LoSlap	PandeiroL Hi	Timbale Lo	
57	BongoBell Mt	PandeiroL Lo	Timbale Side	
58	BongoBell Op	PandeiroL Rm	Timbales Rim	
59	BongoHiSlap1	PandeiroL Sp	TimbalesFil1	
C4 60	BongoHiSlap2	PandeiroMute	TimbalesFil2	Cowbell2 Lng
61	Cabasa Roll	PandeiroOpen	TimbalesFil3	Cowbell2 Edg
62	Caixa Mute	PandeiroRim	TimbalesFil4	Cowbell3 mf
63	Caixa Mute2	PandeiroRoll	TimbalesHand	Cowbell3 f
64	Caixa Open1	PandeiroS Op	Timbles HiMt	Wood Block2H
65	Caixa Open2	PandeiroS Rm	Timbles HiOp	Wood Block2L
66	Caixa Open3	PandeiroS Sp	Timbles LoMt	Claves 2
67	Caixa Rim	Quide Long	Timbles LoOp	Whistle Long
68	Caixa Roll	Quide Short	TmbSideStick	Whistle Shrt
69	Caixa Roll2	Quijada	SectChd 13th	Conga 2H Op
70	Cajon Hi	Rainstick	SectChd m9	Conga 2H Mt
71	Cajon Lo	Real Cabasa1	SectChd Mj9	Conga 2H Slp
C5 72	Cajon Rol Hi	Real Cabasa2	Sabor!	Conga 2L Op
73	Cajon Rol Lo	RecoRecoLng	Arriba!	Conga 2L Mt
74	Caxixi	RecoRecoSht	Ole!	Timbale 3
75	Chekere 1	Repinique1	Uno!	Timbale 4
76	Chekere 2	Repinique2	Dos!	Cabasa 2
77	Chekere 3	RepiniqueHrd	Tres!	Cabasa 2 Cut
78	Clave!	RepiniqueSft	Quatro!	Shaker 1
79	Claves Lo 2	Repique Open	Grito-Hahaha	Guiro 2 Up
80	Conga Hi Mt	Repique Rim	Grito-Ahaha!	Guiro 2 Down
81	Conga Hi Op	Repique Roll	Grito-Haahai	Guiro 2 Fast
82	Conga Link	SambaBateria	Grito-Rrrrr!	Tamborine4 p
83	Conga Lo Mt	SambaWhistle	Tiquitito!	Tamborine4 f
C6 84	Conga Roll	Shaker 1	Grito-Oa Oa!	Cajon 4
85	Conga Slap	Shaker 2	Grito-Eh Eh!	Cuica 2 Hi 8
86	Conga Thumb	Shaker Long	Ama ya ahi!	Cuica 2 Low 8
87	CongaLoOp f	Shaker Short	Fuego!	
88	CongaLoOp mf		Hey Brazil	
89	Cowbell 1			
90	Cowbell 2			
91	Cowbell 3			
92	Cowbell Mt 1			
93	Cowbell Mt 2			
94	Cowbell Op 1			
95	Cowbell Op 2			
C7 96				
97				
98				
99				
100				
101				
102				
103				
104				
105				
106				
107				
C8 108				

	Dr020 GM2 STANDARD	Dr021 GM2 ROOM	Dr022 GM2 POWER	Dr023 GM2 ELECTRIC	Dr024 GM2 ANALOG
21					
22					
23					
C1					
24					
25					
26					
27	High Q	High Q	High Q	High Q	High Q
28	Slap	Slap	Slap	Slap	Slap
29	Scratch Push 7	Scratch Push 7	Scratch Push 7	Scratch Push 7	Scratch Push 7
30	Scratch Pull 7	Scratch Pull 7	Scratch Pull 7	Scratch Pull 7	Scratch Pull 7
31	Sticks	Sticks	Sticks	Sticks	Sticks
32	Square Click	Square Click	Square Click	Square Click	Square Click
33	Metron Click	Metron Click	Metron Click	Metron Click	Metron Click
34	Metron Bell	Metron Bell	Metron Bell	Metron Bell	Metron Bell
35	Kick Drum 2	Kick Drum 2	Power Kick 2	Kick Drum 2	Kick Drum 2
C2					
36	Kick Drum 1	Kick Drum 1	Power Kick 1	Elec.Kick 1	Ana.Kick 1
37	Side Stick	Side Stick	Side Stick	Side Stick	Ana.Rim Sho
38	Aco.Snare	Aco.Snare	PowerSnareDr	E.SnareDrum1	Ana.Snare 1
39	Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
40	Elec.Snare	Elec.Snare	Elec.Snare	E.SnareDrum2	Elec.Snare
41	Low Tom 2	Room LowTom2	PowerLowTom2	E.Low Tom 2	Ana.Low Tom2
42	ClosedHi-hat 1	ClosedHi-hat 1	ClosedHi-hat 1	ClosedHi-hat 1	Ana.ClosedHH 1
43	Low Tom 1	Room LowTom1	PowerLowTom1	E.Low Tom 1	Ana.Low Tom1
44	Pedal Hi-hat 1	Pedal Hi-hat 1	Pedal Hi-hat 1	Pedal Hi-hat 1	Ana.ClosedHH 1
45	Mid Tom 2	Room MidTom2	PowerMidTom2	E.Mid Tom 2	Ana.Mid Tom2
46	Open Hi-hat 1	Open Hi-hat 1	Open Hi-hat 1	Open Hi-hat 1	Ana.Open HH 1
47	Mid Tom 1	Room MidTom1	PowerMidTom1	E.Mid Tom 1	Ana.Mid Tom1
C3					
48	High Tom 2	Room Hi Tom2	Power HiTom2	E.Hi Tom 2	Ana.Hi Tom2
49	CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1	Ana.Cymbal
50	High Tom 1	Room Hi Tom1	Power HiTom1	E.Hi Tom 1	Ana.Hi Tom1
51	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1
52	China Cymbal	China Cymbal	China Cymbal	Reverse Cym.	China Cymbal
53	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
54	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
55	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal
56	Cowbell	Cowbell	Cowbell	Cowbell	Ana.Cowbell
57	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2
58	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap
59	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
C4					
60	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
61	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
62	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga	Ana.Hi Conga
63	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga	Ana.MidConga
64	Low Conga	Low Conga	Low Conga	Low Conga	Ana.LowConga
65	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
66	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
67	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
68	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
69	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
70	Maracas	Maracas	Maracas	Maracas	Ana.Maracas
71	ShortWhistle 2	ShortWhistle 2	ShortWhistle 2	ShortWhistle 2	ShortWhistle 2
C5					
72	Long Whistle 2	Long Whistle 2	Long Whistle 2	Long Whistle 2	Long Whistle 2
73	Short Guiro 3	Short Guiro 3	Short Guiro 3	Short Guiro 3	Short Guiro 3
74	Long Guiro 3	Long Guiro 3	Long Guiro 3	Long Guiro 3	Long Guiro 3
75	Claves	Claves	Claves	Claves	Ana.Claves
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
77	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
78	Mute Cuica 4	Mute Cuica 4	Mute Cuica 4	Mute Cuica 4	Mute Cuica 4
79	Open Cuica 4	Open Cuica 4	Open Cuica 4	Open Cuica 4	Open Cuica 4
80	MuteTriangle 5	MuteTriangle 5	MuteTriangle 5	MuteTriangle 5	MuteTriangle 5
81	OpenTriangle 5	OpenTriangle 5	OpenTriangle 5	OpenTriangle 5	OpenTriangle 5
82	Shaker	Shaker	Shaker	Shaker	Shaker
83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
C6					
84	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
85	Castanets	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo 6	Mute Surdo 6	Mute Surdo 6	Mute Surdo 6	Mute Surdo 6
87	Open Surdo 6	Open Surdo 6	Open Surdo 6	Open Surdo 6	Open Surdo 6
88					
89					
90					
91					
92					
93					
94					
95					
C7					
96					
97					
98					
99					
100					
101					
102					
103					
104					
105					
106					
107					
C8					
108					

Drum Kit Tone List

	Dr025 GM2 JAZZ	Dr026 GM2 BRUSH	Dr027 GM2 ORCHSTRA	Dr028 GM2 SFX
21				
22				
23				
C1 24				
25				
26				
27	High Q	High Q	ClosedHi-hat 1	
28	Slap	Slap	Pedal Hi-hat 1	
29	Scratch Push 7	Scratch Push 7	Open Hi-hat 1	
30	Scratch Pull 7	Scratch Pull 7	Ride Cymbal1	
31	Sticks	Sticks	Sticks	
32	Square Click	Square Click	Square Click	
33	Metron Click	Metron Click	Metron Click	
34	Metron Bell	Metron Bell	Metron Bell	
35	Jazz Kick 2	Jazz Kick 2	Concert BD 2	
C2 36	Jazz Kick 1	Jazz Kick 1	Concert BD 1	
37	Side Stick	Side Stick	Side Stick	
38	Aco.Snare	Brush Tap	Concert SD	
39	Hand Clap	Brush Slap	Castanets	High Q
40	Elec.Snare	Brush Swirl	Concert SD	Slap
41	Low Tom 2	BrushLowTom2	Timpani F	Scratch Push 7
42	ClosedHi-hat 1	ClosedHi-hat 1	Timpani F#	Scratch Pull 7
43	Low Tom 1	BrushLowTom1	Timpani G	Sticks
44	Pedal Hi-hat 1	Pedal Hi-hat 1	Timpani G#	Square Click
45	Mid Tom 2	BrushMidTom2	Timpani A	Metron Click
46	Open Hi-hat 1	Open Hi-hat 1	Timpani A#	Metron Bell
47	Mid Tom 1	BrushMidTom1	Timpani B	GtFret Noise
C3 48	High Tom 2	Brush HiTom2	Timpani c	Cut Noise Up
49	CrashCymbal1	CrashCymbal1	Timpani c#	Cut Noise Dw
50	High Tom 1	Brush HiTom1	Timpani d	Slap_St.Bass
51	Ride Cymbal1	Ride Cymbal1	Timpani d#	Fl.Key Click
52	China Cymbal	China Cymbal	Timpani e	Laughing
53	Ride Bell	Ride Bell	Timpani f	Scream
54	Tambourine	Tambourine	Tambourine	Punch
55	SplashCymbal	SplashCymbal	SplashCymbal	Heart Beat
56	Cowbell	Cowbell	Cowbell	Footsteps 1
57	CrashCymbal2	CrashCymbal2	Concert Cym2	Footsteps 2
58	Vibra-slap	Vibra-slap	Vibra-slap	Applause
59	Ride Cymbal2	Ride Cymbal2	Concert Cym1	Door Creak
C4 60	High Bongo	High Bongo	High Bongo	Door
61	Low Bongo	Low Bongo	Low Bongo	Scratch
62	MuteHi Conga	MuteHi Conga	MuteHi Conga	Wind Chimes
63	OpenHi Conga	OpenHi Conga	OpenHi Conga	Car-Engine
64	Low Conga	Low Conga	Low Conga	Car-Stop
65	High Timbale	High Timbale	High Timbale	Car-Pass
66	Low Timbale	Low Timbale	Low Timbale	Car-Crash
67	High Agogo	High Agogo	High Agogo	Siren
68	Low Agogo	Low Agogo	Low Agogo	Train
69	Cabasa	Cabasa	Cabasa	Jetplane
70	Maracas	Maracas	Maracas	Helicopter
71	ShortWhistle 2	ShortWhistle 2	ShortWhistle 2	Starship
C5 72	Long Whistle 2	Long Whistle 2	Long Whistle 2	Gun Shot
73	Short Guiro 3	Short Guiro 3	Short Guiro 3	Machine Gun
74	Long Guiro 3	Long Guiro 3	Long Guiro 3	Lasergun
75	Claves	Claves	Claves	Explosion
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Dog
77	LowWoodBlock	LowWoodBlock	LowWoodBlock	Horse-Gallop
78	Mute Cuica 4	Mute Cuica 4	Mute Cuica 4	Birds
79	Open Cuica 4	Open Cuica 4	Open Cuica 4	Rain
80	MuteTriangle 5	MuteTriangle 5	MuteTriangle 5	Thunder
81	OpenTriangle 5	OpenTriangle 5	OpenTriangle 5	Wind
82	Shaker	Shaker	Shaker	Seashore
83	Jingle Bell	Jingle Bell	Jingle Bell	Stream
C6 84	Bell Tree	Bell Tree	Bell Tree	Bubble
85	Castanets	Castanets	Castanets	
86	Mute Surdo 6	Mute Surdo 6	Mute Surdo 6	
87	Open Surdo 6	Open Surdo 6	Open Surdo 6	
88			Applause	
89				
90				
91				
92				
93				
94				
95				
C7 96				
97				
98				
99				
100				
101				
102				
103				
104				
105				
106				
107				
C8 108				