## **MIDI Implementation Chart**

Date: Aug. 28. 2015 Version: 1.0

Function	on	Transmitted	Received	Remarks
Basic Channel	Default Change	1–16 1–16	1–16 1–16	Memorized
Mode	Default Messages Altered	X O *******	X X	*1
Note Number	True Voice	0–127 *******	X X	
Velocity	Note On Note Off	O 9n, v=1–127 X 8n, v=64	X X	
After Touch	Key's Channel	X X	X X	
Pitch Bend		0	Х	Joystick *2
Control Change	0–127	0	X	Joystick, SUSTAIN button *2 *3
Program Change	True Number	X *******	X *******	
System Exclusive		0	0	*4
System Common	Song Position Song Select Tune Request	X X X	X X X	
System Real Time	Clock Commands	X X	0	*5 *6 *5 *6
Aux Meassages	Local On/Off All Notes Off Active Sense System Reset	O O X X	X X X	*1 *1

## Notes

- \*1: Valid if assigned as a MIDI control change.
- \*2: Transmit if arpeggiator is off.
- \*3: All control change numbers are valid if assigned to Joystick or SUSTAIN button.
- \*4: In addition to Korg exclusive messages, also responds to inquiry messages.
- \*5: Received while using arpeggiator if MIDI clock is set to Auto or External.
- \*6: Received only during USB connection.

Mode 1: Omni On, Poly Mode 3: Omni Off, Poly Mode 2: Omni On, Mono Mode 4: Omni Off, Mono O: Yes X: No

## **MIDI Implementation Chart**

Date: Aug. 28. 2015 Version: 2.0

Wodel. Microre 1 20				
Function	on	Transmitted	Received	Remarks
Basic Channel	Default Change	1–16 1–16	1–16 1–16	Memorized
Mode	Default Messages Altered	X O *******	X X	*1
Note Number	True Voice	0–127 *******	X X	
Velocity	Note On Note Off	O 9n, v=1–127 X 8n, v=64	X X	
After Touch	Key's Channel	X X	X X	
Pitch Bend		0	Х	Joystick *2
Control Change	0–127	0	X	Joystick, SUSTAIN button *2 *3
Program Change	True Number	X *******	X ******	
System Exclusive		0	0	*4
System Common	Song Position Song Select Tune Request	X X X	X X X	
System Real Time	Clock Commands	X X	0	*5 *5
Aux Meassages	Local On/Off All Notes Off Active Sense System Reset	O O X X	X X X	*1 *1

## Notes

- \*1: Valid if assigned as a MIDI control change.
- \*2: Transmit if arpeggiator is off.
- \*3: All control change numbers are valid if assigned to Joystick or SUSTAIN button.
- \*4: In addition to Korg exclusive messages, also responds to inquiry messages.
- \*5: Received while using arpeggiator if MIDI clock is set to Auto or External.

Mode 1: Omni On, Poly Mode 3: Omni Off, Poly Mode 2: Omni On, Mono Mode 4: Omni Off, Mono O: Yes X: No